



LABORATORY DATA CONSULTANTS, INC.

7750 El Camino Real, Suite 2L Carlsbad, CA 92009 Phone: 760/634-0437 Fax: 760/634-0439

ERM
2525 Natomas Park Drive, Suite 350
Sacramento, CA 95833
ATTN: Ms. Maria Barajas-Albalawi

August 15, 2008

SUBJECT: BRC Tronox Parcel C, Data Validation

Dear Ms. Barajas-Albalawi

Enclosed are the final validation reports for the fractions listed below. This SDG was received on July 28, 2008. Attachment 1 is a summary of the samples that were reviewed for each analysis.

LDC Project # 19191:

<u>SDG #</u>	<u>Fraction</u>
F8F130140	Volatiles, Semivolatiles, Chlorinated Pesticides, Polychlorinated Biphenyls, Metals, Wet Chemistry, Gasoline Range Organics, Diesel Range Organics, Polynuclear Aromatic Hydrocarbons, Dioxins/Dibenzofurans

The data validation was performed under EPA Level III and Level IV guidelines. The analyses were validated using the following documents, as applicable to each method:

- USEPA, Contract Laboratory Program National Functional Guidelines for Organic Data Review, October 1999
- USEPA, Contract Laboratory Program National Functional Guidelines for Inorganic Data Review, October 2004
- EPA SW 846, Third Edition, Test Methods for Evaluating Solid Waste, update 1, July 1992; update IIA, August 1993; update II, September 1994; update IIB, January 1995; update III, December 1996; update IIIA, April 1998; IIIB, November 2004; Update IV, February 2007

Please feel free to contact us if you have any questions.

Sincerely,

Erlinda T. Rauto
Operations Manager/Senior Chemist

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Volatiles
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

RINSATE-2
TB-2
TSB-CJ-09-0
TSB-CJ-09-10**
TB-1 6/12/08
TB-2 6/12/08
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 6 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8260B for Volatiles.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section V.

Field duplicates are summarized in Section XVI.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UJ Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. GC/MS Instrument Performance Check

Instrument performance was checked at 12 hour intervals.

All ion abundance requirements were met.

III. Initial Calibration

Initial calibration was performed using required standard concentrations.

Percent relative standard deviations (%RSD) were less than or equal to 15.0% for each individual compound and less than or equal to 30.0% for calibration check compounds (CCCs).

In the case where %RSD was greater than 15.0%, the laboratory used a calibration curve to evaluate the compound. All coefficients of determination (r^2) were greater than or equal to 0.990 .

For the purposes of technical evaluation, all compounds were evaluated against the 30.0% (%RSD) National Functional Guideline criteria. Unless noted above, all compounds were within the validation criteria.

Average relative response factors (RRF) for all volatile target compounds and system performance check compounds (SPCCs) were within method and validation criteria with the following exceptions:

Date	Compound	RRF (Limits)	Associated Samples	Flag	A or P
6/9/08	Ethanol	0.00221 (≥ 0.05)	All soil samples in SDG F8F130140	J (all detects) UJ (all non-detects)	A

IV. Continuing Calibration

Continuing calibration was performed at the required frequencies.

Percent differences (%D) between the initial calibration RRF and the continuing calibration RRF were within the method criteria of less than or equal to 20.0% for calibration check compounds (CCCs).

For the purposes of technical evaluation, all compounds were evaluated against the 25.0% (%D) National Functional Guideline criteria. Unless noted above, all compounds were within the validation criteria with the following exceptions:

Date	Compound	%D	Associated Samples	Flag	A or P
6/19/08	Iodomethane	67.71684	All water samples in SDG F8F130140	J+ (all detects)	A

The percent differences (%D) of the second source calibration standard were less than or equal to 25.0% for all compounds with the following exceptions:

Date	Compound	%D	Associated Samples	Flag	A or P
5/28/08	Iodomethane	31.67513	All water samples in SDG F8F130140	J+ (all detects)	A
5/28/08	2-Hexanone	25.04476	All water samples in SDG F8F130140	J- (all detects) UJ (all non-detects)	A

All of the continuing calibration RRF values were within method and validation criteria with the following exceptions:

Date	Compound	RRF (Limits)	Associated Samples	Flag	A or P
6/16/08	Ethanol	0.00209 (≥0.05)	All soil samples in SDG F8F130140	J (all detects) UJ (all non-detects)	A

V. Blanks

Method blanks were reviewed for each matrix as applicable. No volatile contaminants were found in the method blanks.

Samples TB-2, TB-1 6/12/08, and TB-2 6/12/08 were identified as trip blanks. No volatile contaminants were found in these blanks with the following exceptions:

Trip Blank ID	Sampling Date	Compound	Concentration	Associated Samples
TB-2	6/12/08	Acetone Chloroform	2.8 ug/L 0.14 ug/L	RINSATE-2
TB-1 6/12/08	6/12/08	Chloroform Dichloromethane	0.11 ug/L 0.41 ug/L	All soil samples in SDG F8F130140

Trip Blank ID	Sampling Date	Compound	Concentration	Associated Samples
TB-2 6/12/08	6/12/08	Acetone	1.7 ug/L	RINSATE-2

Sample RINSATE-2 was identified as a rinsate. No volatile contaminants were found in this blank with the following exceptions:

Rinsate ID	Sampling Date	Compound	Concentration	Associated Samples
RINSATE-2	6/12/08	Chloromethane Dichloromethane Toluene	0.25 ug/L 2.8 ug/L 0.22 ug/L	All soil samples in SDG F8F130140

Sample concentrations were compared to concentrations detected in the field blanks. The sample concentrations were either not detected or were significantly greater (>10X for common contaminants, >5X for other contaminants) than the concentrations found in the associated field blanks with the following exceptions:

Sample	Compound	Reported Concentration	Modified Final Concentration
TSB-CJ-09-0	Toluene	0.49 ug/Kg	5.2U ug/Kg

VI. Surrogate Spikes

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits with the following exceptions:

Sample	Surrogate	%R (Limits)	Compound	Flag	A or P
8172125MB	Bromofluorobenzene	117 (79-115)	All TCL compounds	J+ (all detects)	P
RINSATE-2	Bromofluorobenzene	117 (79-115)	Nonanal Dimethyl disulfide	J+ (all detects) J+ (all detects)	A

VII. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Although the MS/MSD percent recoveries (%R) or and relative percent difference (RPD) were not within QC limits for some compounds, the MS, MSD, or LCS percent recovery (%R) was within QC limits and no data were qualified.

VIII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. Although the percent recoveries (%R) and relative percent difference (RPD) for some compounds in the LCS/LCSD were not within QC limits, the MS/MSD percent recoveries (%R) were within QC limits and no data were qualified.

IX. Regional Quality Assurance and Quality Control

Not applicable.

X. Internal Standards

All internal standard areas and retention times were within QC limits.

XI. Target Compound Identifications

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XII. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XIII. Tentatively Identified Compounds (TICs)

Tentatively identified compounds were not reported by the laboratory.

XIV. System Performance

The system performance was acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XV. Overall Assessment of Data

Data flags are summarized at the end of the report if data has been qualified.

XVI. Field Duplicates

No field duplicates were identified in this SDG.

BRC Parcel C
Volatiles - Data Qualification Summary - SDG F8F130140

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Ethanol	J (all detects) UJ (all non-detects)	A	Initial calibration (RRF)
F8F130140	RINSATE-2 TB-2 TB-1 6/12/08 TB-2 6/12/08	Iodomethane	J+ (all detects)	A	Continuing calibration (%D)
F8F130140	RINSATE-2 TB-2 TB-1 6/12/08 TB-2 6/12/08	Iodomethane	J+ (all detects)	A	Continuing calibration (ICV %D)
F8F130140	RINSATE-2 TB-2 TB-1 6/12/08 TB-2 6/12/08	2-Hexanone	J- (all detects) UJ (all non-detects)	A	Continuing calibration (ICV %D)
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Ethanol	J (all detects) UJ (all non-detects)	A	Continuing calibration (RRF)
F8F130140	RINSATE-2	Nonanal Dimethyl disulfide	J+ (all detects) J+ (all detects)	A	Surrogate recovery (%R)

BRC Parcel C
Volatiles - Laboratory Blank Data Qualification Summary - SDG F8F130140

No Sample Data Qualified in this SDG

BRC Parcel C
Volatiles - Field Blank Data Qualification Summary - SDG F8F130140

SDG	Sample	Compound	Modified Final Concentration	A or P
F8F130140	TSB-CJ-09-0	Toluene	5.2U ug/Kg	A

LDC #: 19191A1

VALIDATION COMPLETENESS WORKSHEET

SDG #: F8F130140

Level III/IV

Laboratory: Test America

Date: 8/5/08

Page: 1 of 1

Reviewer: [Signature]

2nd Reviewer: [Signature]

METHOD: GC/MS Volatiles (EPA SW 846 Method 8260B)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
II.	GC/MS Instrument performance check	A	
III.	Initial calibration	W	PSD. 12
IV.	Continuing calibration/ICV	W	ICV = 2570
V.	Blanks	A	
VI.	Surrogate spikes	W	
VII.	Matrix spike/Matrix spike duplicates	W	
VIII.	Laboratory control samples	W	CCS 7
IX.	Regional Quality Assurance and Quality Control	N	
X.	Internal standards	A	
XI.	Target compound identification	A	Not reviewed for Level III validation.
XII.	Compound quantitation/CRQLs	A	Not reviewed for Level III validation.
XIII.	Tentatively identified compounds (TICs)	N	Not reviewed for Level III validation.
XIV.	System performance	A	Not reviewed for Level III validation.
XV.	Overall assessment of data	A	
XVI.	Field duplicates	N	
XVII.	Field blanks	W	R=1. TB=2. S. 6

Note: A = Acceptable
N = Not provided/applicable
SW = See worksheet

ND = No compounds detected
R = Rinsate
FB = Field blank

D = Duplicate
TB = Trip blank
EB = Equipment blank

Validated Samples:

** Indicates sample underwent Level IV validation

1 1/3	RINSATE-2	W	11	8170291MB	21	S	31
2 1/2	TB-2	↓	12	8172125MB	22	W	32
3	TSB-CJ-09-0	S	13	8172361MB	23	W (N)	33
4	TSB-CJ-09-10**	↓	14	8172539MB	24	V (N.D)	34
5 1/2	TB-1 6/12/08	↓	15		25		35
6 1/2	TB-2 6/12/08	↓	16		26		36
7	RINSATE-2MS	↓	17		27		37
8	RINSATE-2MSD	↓	18		28		38
9	TSB-CJ-09-0MS	S	19		29		39
10	TSB-CJ-09-0MSD	↓	20		30		40

LDC #: 19191A1
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: Volatiles (EPA SW 846 Method 8260B)

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Cooler temperature criteria was met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
II. GC/MS instrument performance check				
Were the BFB performance results reviewed and found to be within the specified criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all samples analyzed within the 12 hour clock criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
III. Initial calibration				
Did the laboratory perform a 5 point calibration prior to sample analysis?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent relative standard deviations (%RSD) and relative response factors (RRF) within method criteria for all CCCs and SPCCs?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a curve fit used for evaluation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Did the initial calibration meet the curve fit acceptance criteria of > 0.990?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent relative standard deviations (%RSD) ≤ 30% and relative response factors (RRF) > 0.05?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
IV. Continuing calibration				
Was a continuing calibration standard analyzed at least once every 12 hours for each instrument?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent differences (%D) and relative response factors (RRF) within method criteria for all CCCs and SPCCs?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent differences (%D) ≤ 25% and relative response factors (RRF) ≥ 0.05?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
V. Blanks				
Was a method blank associated with every sample in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a method blank analyzed at least once every 12 hours for each matrix and concentration?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VI. Surrogate spikes				
Were all surrogate %R within QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
If the percent recovery (%R) for one or more surrogates was out of QC limits, was a reanalysis performed to confirm samples with %R outside of criteria?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VII. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a MS/MSD analyzed every 20 samples of each matrix?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VIII. Laboratory control samples				
Was an LCS analyzed for this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

LDC #: PP1A1
 SDG #: see cover

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Was an LCS analyzed per analytical batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
IX. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
X. Internal standards				
Were internal standard area counts within -50% or +100% of the associated calibration standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were retention times within + 30 seconds of the associated calibration standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Target compound identification				
Were relative retention times (RRT's) within + 0.06 RRT units of the standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Did compound spectra meet specified EPA "Functional Guidelines" criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were chromatogram peaks verified and accounted for?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. Compound quantitation/CRQLs				
Were the correct internal standard (IS), quantitation ion and relative response factor (RRF) used to quantitate the compound?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Tentatively identified compounds (TICs)				
Were the major ions (> 10 percent relative intensity) in the reference spectrum evaluated in sample spectrum?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Were relative intensities of the major ions within ± 20% between the sample and the reference spectra?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Did the raw data indicate that the laboratory performed a library search for all required peaks in the chromatograms (samples and blanks)?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
XIV. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XV. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XVI. Field duplicates				
Field duplicate pairs were identified in this SDG.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Target compounds were detected in the field duplicates.	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XVII. Field blanks				
Field blanks were identified in this SDG.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Target compounds were detected in the field blanks.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

TARGET COMPOUND WORKSHEET

METHOD: VOA (EPA SW 846 Method 8260B)

A. Chloromethane*	U. 1,1,2-Trichloroethane	OO. 2,2-Dichloropropane	III. n-Butylbenzene	CCCC. 1-Chlorohexane
B. Bromomethane	V. Benzene	PP. Bromochloromethane	JJ. 1,2-Dichlorobenzene	DDDD. Isopropyl alcohol
C. Vinyl chloride**	W. trans-1,3-Dichloropropene	QQ. 1,1-Dichloropropene	KKK. 1,2,4-Trichlorobenzene	EEEE. Acetonitrile
D. Chloroethane	X. Bromoform*	RR. Dibromomethane	LLL. Hexachlorobutadiene	FFFF. Acrolein
E. Methylene chloride	Y. 4-Methyl-2-pentanone	SS. 1,3-Dichloropropane	MMM. Naphthalene	GGGG. Acrylonitrile
F. Acetone	Z. 2-Hexanone	TT. 1,2-Dibromoethane	NNN. 1,2,3-Trichlorobenzene	HHHH. 1,4-Dioxane
G. Carbon disulfide	AA. Tetrachloroethene	UU. 1,1,1,2-Tetrachloroethane	OOO. 1,3,5-Trichlorobenzene	IIII. Isobutyl alcohol
H. 1,1-Dichloroethene**	BB. 1,1,2,2-Tetrachloroethane*	VV. Isopropylbenzene	PPP. trans-1,2-Dichloroethene	JJJJ. Methacrylonitrile
I. 1,1-Dichloroethane*	CC. Toluene**	WW. Bromobenzene	QQQ. cis-1,2-Dichloroethene	KKKK. Propionitrile
J. 1,2-Dichloroethene, total	DD. Chlorobenzene*	XX. 1,2,3-Trichloropropane	RRR. m,p-Xylenes	LLLL. Ethyl ether
K. Chloroform**	EE. Ethylbenzene**	YY. n-Propylbenzene	SSS. o-Xylene	MMMM. Benzyl chloride
L. 1,2-Dichloroethane	FF. Styrene	ZZ. 2-Chlorotoluene	TTT. 1,1,2-Trichloro-1,2,2-trifluoroethane	NNNN. <i>2,2-Dimethyl pentanol</i>
M. 2-Butanone	GG. Xylenes, total	AAA. 1,3,5-Trimethylbenzene	UUU. 1,2-Dichlorotetrafluoroethane	OOOO. <i>Dimethyl disulfide</i>
N. 1,1,1-Trichloroethane	HH. Vinyl acetate	BBB. 4-Chlorotoluene	VVV. 4-Ethyltoluene	PPPP.
O. Carbon tetrachloride	II. 2-Chloroethylvinyl ether	CCC. tert-Butylbenzene	WWW. Ethanol	QQQQ.
P. Bromodichloromethane	JJ. Dichlorodifluoromethane	DDD. 1,2,4-Trimethylbenzene	XXX. Di-isopropyl ether	RRRR.
Q. 1,2-Dichloropropane**	KK. Trichlorofluoromethane	EEE. sec-Butylbenzene	YYY. tert-Butanol	SSSS.
R. cis-1,3-Dichloropropene	LL. Methyl-tert-butyl ether	FFF. 1,3-Dichlorobenzene	ZZZ. tert-Butyl alcohol	TTTT.
S. Trichloroethene	MM. 1,2-Dibromo-3-chloropropane	GGG. p-Isopropyltoluene	AAAA. Ethyl tert-butyl ether	UUUU.
T. Dibromochloromethane	NN. Methyl ethyl ketone	HHH. 1,4-Dichlorobenzene	BBBB. tert-Amyl methyl ether	VVVV.

* = System performance check compounds (SPCC) for RRF ; ** = Calibration check compounds (CCC) for %RSD.

VALIDATION FINDINGS WORKSHEET
Field Blanks

Page: 6 of 7
Reviewer: _____
2nd Reviewer: RS

LDC #: 19191A
SDG #: See order

METHOD: GC/MS VOA (EPA SW 846 Method 8260)

N/A Were field blanks identified in this SDG?
N/A Were target compounds detected in the field blanks?
Blank units: None Associated sample units: 100K
Sampling date: 6/2/18
Field blank type: (circle one) Field Blank / Rinsate / Trip Blank / Other: Trip Blank Associated Samples: All soils

Compound	Blank ID	Sample Identification
	<u>5</u>	
Methylene chloride		
Acetone		
Chloroform	<u>0.11</u>	
<u>Dichloromethane</u>	<u>0.4</u>	
CRQL		

Blank units: _____ Associated sample units: _____
Sampling date: _____
Field blank type: (circle one) Field Blank / Rinsate / Trip Blank / Other: _____ Associated Samples: _____

Compound	Blank ID	Sample Identification
Methylene chloride		
Acetone		
Chloroform		
CRQL		

CIRCLED RESULTS WERE NOT QUALIFIED. ALL RESULTS NOT CIRCLED WERE QUALIFIED BY THE FOLLOWING STATEMENT:
Common contaminants such as Methylene chloride, Acetone, 2-Butanone and Carbon disulfide that were detected in samples within ten times the associated field blank concentration were qualified as not detected, "U". Other contaminants within five times the field blank concentration were also qualified as not detected, "U".

VALIDATION FINDINGS WORKSHEET
Field Blanks

Page: 4 of 9
Reviewer: [Signature]
2nd Reviewer: [Signature]

LDC #: 1919A
SDG #: See above

METHOD: GC/MS VOA (EPA SW 846 Method 8260)

Were field blanks identified in this SDG? Y
Were target compounds detected in the field blanks? N
Blank units: None Associated sample units: None
Sampling date: 6/12/18
Field blank type: (circle one) Field Blank (Rinsate) / Trip Blank / Other: all soils

Compound	Blank ID	Sample Identification
Methylene chloride	1	
Acetone		
Chloroform		
A	0.75	
Dichloromethane	2.8	
CC	0.22	
CRQL	0.49/5.0	

Blank units: None Associated sample units: None
Sampling date: 6/12/18
Field blank type: (circle one) Field Blank (Rinsate) / Trip Blank / Other: None

Compound	Blank ID	Sample Identification
Methylene chloride	2	
Acetone		
Chloroform		
	6	
	1.7	
	0.14	
CRQL		

CIRCLED RESULTS WERE NOT QUALIFIED. ALL RESULTS NOT CIRCLED WERE QUALIFIED BY THE FOLLOWING STATEMENT:
Common contaminants such as Methylene chloride, Acetone, 2-Butanone and Carbon disulfide that were detected in samples within ten times the associated field blank concentration were qualified as not detected, "U". Other contaminants within five times the field blank concentration were also qualified as not detected, "U".

LDC #: PA1A1
 SDG #: See Com

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 1 of 1
 Reviewer: g
 2nd Reviewer: l

METHOD: GC/MS VOA (EPA SW 846 Method 8260B)

The Relative Response Factor (RRF), average RRF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

$RRF = (A_s)(C_s)/(A_x)(C_x)$
 average RRF = sum of the RRFs/number of standards
 $\%RSD = 100 * (S/X)$
 A_s = Area of compound,
 C_s = Concentration of compound,
 S = Standard deviation of the RRFs
 X = Mean of the RRFs
 A_x = Area of associated internal standard
 C_x = Concentration of internal standard

#	Standard ID	Calibration Date	Compound (Reference Internal Standard)	Reported		Recalculated		Reported		Recalculated	
				RRF (std)	RRF (std)	RRF (std)	Average RRF (Initial)	Average RRF (Initial)	%RSD	%RSD	
1	1CAL (F)	6/9/08	K (1st internal standard)	0.50971	0.50971	0.50831	0.50831	7.04091	7.0405		
			AA (2nd internal standard)	0.25572	0.25572	0.29404	0.29404	12.7450	12.7450		
			DD (3rd internal standard)	3.57047	3.57047	3.42599	3.42599	8.25563	8.2556		
2	1CAL (F)	6/9/08	NNN (1st internal standard)	0.74129	0.74129	0.73871	0.73871	2.56798	2.5677		
			OOO (2nd internal standard)	0.59203	0.59203	0.55366	0.55366	13.4744	13.4718		
			OOO (3rd internal standard)	1.11568	1.11568	1.11150	1.11150	2.41699	2.4169		
3			(1st internal standard)								
			(2nd internal standard)								
			(3rd internal standard)								
4			(1st internal standard)								
			(2nd internal standard)								
			(3rd internal standard)								

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

METHOD: GC/MS VOA (EPA SW 846 Method 8260B)

The percent difference (%D) of the initial calibration average Relative Response Factors (RRFs) and the continuing calibration RRFs were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \times (\text{ave. RRF} - \text{RRF}) / \text{ave. RRF}$ Where: ave. RRF = initial calibration average RRF
 $\text{RRF} = (A_s)(C_i) / (A_s)(C_s)$ RRF = continuing calibration RRF
 A_s = Area of compound, A_w = Area of associated internal standard
 C_s = Concentration of compound, C_w = Concentration of internal standard

#	Standard ID	Calibration Date	Compound (Reference internal Standard)	Average RRF (Initial)	Reported		Recalculated	
					RRF (CC)	%D	RRF (CC)	%D
1	FEA-117D	6/16/08	K (1st internal standard)	0.50831	0.57288	0.89949	0.57288	0.899
			AA (2nd internal standard)	0.29404	0.31216	6.16168	0.31216	6.1612
			DDP (3rd internal standard)	3.42599	3.65203	6.59782	3.65203	6.5978
2	FEA-117T	6/16/08	NNNN (1st internal standard)	0.73871	0.72154	2.32412	0.72154	2.3244
			OOO (2nd internal standard)	0.55366	0.57358	3.59757	0.57358	3.5985
			PPP (3rd internal standard)	1.11150	1.10470	0.61152	1.10470	0.6118
3			(1st internal standard)					
			(2nd internal standard)					
			(3rd internal standard)					
4			(1st internal standard)					
			(2nd internal standard)					
			(3rd internal standard)					

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A
 SDG #: See CDW

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

Page: 6 of 1
 Reviewer: [Signature]
 2nd reviewer: [Signature]

METHOD: GC/MS VOA (EPA SW 846 Method 8260B)

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: $SF/SS * 100$

Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 4

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Toluene-d8	50	45.0916	90	90	0
Bromofluorobenzene	↓	42.0950	84	84	↓
1,2-Dichloroethane-d4	↓	48.4101	97	97	↓
Dibromofluoromethane	↓	43.2435	86	86	↓

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Toluene-d8					
Bromofluorobenzene					
1,2-Dichloroethane-d4					
Dibromofluoromethane					

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Toluene-d8					
Bromofluorobenzene					
1,2-Dichloroethane-d4					
Dibromofluoromethane					

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Toluene-d8					
Bromofluorobenzene					
1,2-Dichloroethane-d4					
Dibromofluoromethane					

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Toluene-d8					
Bromofluorobenzene					
1,2-Dichloroethane-d4					
Dibromofluoromethane					

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

METHOD: GC/MS VOA (EPA SW 846 Method 8260B)

The percent recoveries (%R) and Relative Percent Difference (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC - SC) / SA$ Where: SSC = Spiked sample concentration SC = Sample concentration
 SA = Spike added

RPD = $|MSC - MSC1| * 2 / (MSC + MSC1)$ MSC = Matrix spike concentration MSC1 = Matrix spike duplicate concentration

MS/MSD sample: 9/10

Compound	Spike Added (1/45)		Sample Concentration (1/45)	Spiked Sample Concentration (1/45)		Matrix Spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalculated
1,1-Dichloroethene	52.4	58.0	ND	41.6	42.8	79	79	82	82	2.9	2.8
Trichloroethene			↓	49.1	49.9	94	94	96	96	1.5	1.6
Benzene			0.49	46.9	47.6	90	90	91	91	1.4	1.5
Toluene			ND	47.0	47.8	89	89	91	91	1.8	1.7
Chlorobenzene			ND	46.4	47.0	89	89	90	90	1.2	1.3

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 1919A1
 SDG #: 52200W

VALIDATION FINDINGS WORKSHEET
Laboratory Control Sample Results Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC/MS VOA (EPA SW 846 Method 8260B)

The percent recoveries (%R) and Relative Percent Difference (RPD) of the laboratory control sample and laboratory control sample duplicate (if applicable) were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * \frac{SSC}{SA}$ Where: SSC = Spiked sample concentration
 SA = Spike added
 RPD = $\frac{|LCSC - LCSDC| * 2}{(LCSC + LCSDC)}$ LCSC = Laboratory control sample concentration LCSDC = Laboratory control sample duplicate concentration
 LCS ID: 8170291

Compound	Spike Added (mg/L)		Spiked Sample Concentration (mg/L)		LCS		LCSDC		Percent Recovery		Percent Recovery		RPD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.		
1,1-Dichloroethene	50	NA	47.8	NA	96	96								
Trichloroethene			49.5		99	99								
Benzene			49.6		99	99								
Toluene			50.2		100	100								
Chlorobenzene			49.9		100	100								

Comments: Refer to Laboratory Control Sample findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LCCLC.15B

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Semivolatiles
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8270C for Semivolatiles.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section V.

Field duplicates are summarized in Section XVI.

Samples indicated by a double asterisk on the front cover underwent a EPA Level IV review. A EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. GC/MS Instrument Performance Check

Instrument performance was checked at 12 hour intervals.

All ion abundance requirements were met.

III. Initial Calibration

Initial calibration was performed using required standard concentrations.

Percent relative standard deviations (%RSD) were less than or equal to 15.0% for each individual compound and less than or equal to 30.0% for calibration check compounds (CCCs).

In the case where %RSD was greater than 15.0%, the laboratory used a calibration curve to evaluate the compound. All coefficients of determination (r^2) were greater than or equal to 0.990 .

For the purposes of technical evaluation, all compounds were evaluated against the 30.0% (%RSD) National Functional Guideline criteria. Unless noted above, all compounds were within the validation criteria.

Average relative response factors (RRF) for all semivolatile target compounds and system performance check compounds (SPCCs) were greater than or equal to 0.05 as required with the following exceptions:

Date	Compound	RRF (Limits)	Associated Samples	Flag	A or P
6/18/08	Phthalic acid	0.01422 (≥ 0.05)	All samples in SDG F8F130140	J (all detects)	A
	N-(Hydroxymethyl)phthalimide	0.04408 (≥ 0.05)		UJ (all non-detects)	
				J (all detects)	
				UJ (all non-detects)	

IV. Continuing Calibration

Continuing calibration was performed at the required frequencies.

Percent differences (%D) between the initial calibration RRF and the continuing calibration RRF were within the method criteria of less than or equal to 20.0% for calibration check compounds (CCCs).

For the purposes of technical evaluation, all compounds were evaluated against the 25.0% (%D) National Functional Guideline criteria. Unless noted above, all compounds were within the validation criteria with the following exceptions:

Date	Compound	%D	Associated Samples	Flag	A or P
6/19/08	Phthalic acid	25.06878	All samples in SDG F8F130140	J- (all detects) UJ (all non-detects)	A

The percent difference (%D) of the second source calibration standard were less than or equal to 25.0% for all compounds.

All of the continuing calibration RRF values were within method and validation criteria with the following exceptions:

Date	Compound	RRF (Limits)	Associated Samples	Flag	A or P
6/19/08	Phthalic acid	0.01066 (≥ 0.05)	All samples in SDG F8F130140	J (all detects) UJ (all non-detects)	A
	N-(Hydroxymethyl)phthalimide	0.04523 (≥ 0.05)		J (all detects) UJ (all non-detects)	

V. Blanks

Method blanks were reviewed for each matrix as applicable. No semivolatile contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No semivolatile contaminants were found in this blank.

VI. Surrogate Spikes

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits.

VII. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

VIII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) were within QC limits. Although the percent recovery (%R) for one compound in the LCS was not within QC limits, the MS/MSD percent recoveries (%R) were within QC limits and no data were qualified.

IX. Regional Quality Assurance and Quality Control

Not applicable.

X. Internal Standards

All internal standard areas and retention times were within QC limits.

XI. Target Compound Identifications

All target compound identifications were within validation criteria for samples on which a EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XII. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which a EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XIII. Tentatively Identified Compounds (TICs)

Tentatively identified compounds were not reported by the laboratory.

XIV. System Performance

The system performance was acceptable for samples on which a EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XV. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

XVI. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Parcel C
Semivolatiles - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	RINSATE-2 TSB-CJ-09-0 TSB-CJ-09-10**	Phthalic acid N-(Hydroxymethyl)phthalimide	J (all detects) UJ (all non-detects) J (all detects) UJ (all non-detects)	A	Initial calibration (RRF)
F8F130140	RINSATE-2 TSB-CJ-09-0 TSB-CJ-09-10**	Phthalic acid	J- (all detects) UJ (all non-detects)	A	Continuing calibration (%D)
F8F130140	RINSATE-2 TSB-CJ-09-0 TSB-CJ-09-10**	Phthalic acid N-(Hydroxymethyl)phthalimide	J (all detects) UJ (all non-detects) J (all detects) UJ (all non-detects)	A	Continuing calibration (RRF)

**BRC Parcel C
Semivolatiles - Laboratory Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Parcel C
Semivolatiles - Field Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A2
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET

Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC/MS Semivolatiles (EPA SW 846 Method 8270C)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
II.	GC/MS Instrument performance check	A	
III.	Initial calibration	SW	
IV.	Continuing calibration/ICV	W	ICV ≤ 25%
V.	Blanks	A	
VI.	Surrogate spikes	A	
VII.	Matrix spike/Matrix spike duplicates	A	
VIII.	Laboratory control samples	W	LC9
IX.	Regional Quality Assurance and Quality Control	N	
X.	Internal standards	A	
XI.	Target compound identification	A	Not reviewed for Level III validation.
XII.	Compound quantitation/CRQLs	A	Not reviewed for Level III validation.
XIII.	Tentatively identified compounds (TICs)	N	Not reviewed for Level III validation.
XIV.	System performance	A	Not reviewed for Level III validation.
XV.	Overall assessment of data	A	
XVI.	Field duplicates	N	
XVII.	Field blanks	ND	R=1. [Signature]

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	816835 MB	21	W	31
2	TSB-CJ-09-0	S	12	8170309 MB	22	S	32
3	TSB-CJ-09-10**	↓	13		23		33
4	RINSATE-2MS	W	14		24		34
5	RINSATE-2MSD	↓	15		25		35
6	TSB-CJ-09-0MS	S	16		26		36
7	TSB-CJ-09-0MSD	↓	17		27		37
8	RINSATE-1	W	18		28		38
9			19		29		39
10			20		30		40

LDC #: 1919182
 SDG #: 78FT30140

VALIDATION FINDINGS CHECKLIST

Page: 6 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: Semivolatiles (EPA SW 846 Method 8270C)

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	/			
Cooler temperature criteria was met.	/			
II. GC/MS Instrument performance check				
Were the DFTPP performance results reviewed and found to be within the specified criteria?	/			
Were all samples analyzed within the 12 hour clock criteria?	/			
III. Initial calibration				
Did the laboratory perform a 5 point calibration prior to sample analysis?	/			
Were all percent relative standard deviations (%RSD) and relative response factors (RRF) within method criteria for all CCCs and SPCCs?	/			
Was a curve fit used for evaluation?		/		
Did the initial calibration meet the curve fit acceptance criteria of ≥ 0.990 ?			/	
Were all percent relative standard deviations (%RSD) $\leq 30\%$ and relative response factors (RRF) > 0.05 ?		/		
IV. Continuing calibration				
Was a continuing calibration standard analyzed at least once every 12 hours for each instrument?	/			
Were all percent differences (%D) and relative response factors (RRF) within method criteria for all CCCs and SPCCs?	/			
Were all percent differences (%D) $\leq 25\%$ and relative response factors (RRF) ≥ 0.05 ?		/		
V. Blanks				
Was a method blank associated with every sample in this SDG?	/			
Was a method blank analyzed for each matrix and concentration?	/			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.		/		
VI. Surrogate spikes				
Were all surrogate %R within QC limits?	/			
If 2 or more base neutral or acid surrogates were outside QC limits, was a reanalysis performed to confirm %R?			/	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?			/	
VII. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	/			
Was a MS/MSD analyzed every 20 samples of each matrix?	/			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	/			
VIII. Laboratory control samples				
Was an LCS analyzed for this SDG?	/			

LDC #: 19191A2
 SDG #: FS720140

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
IX. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
X. Internal standards				
Were internal standard area counts within -50% or +100% of the associated calibration standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were retention times within + 30 seconds from the associated calibration standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Target compound identification				
Were relative retention times (RRT's) within + 0.06 RRT units of the standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Did compound spectra meet specified EPA "Functional Guidelines" criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were chromatogram peaks verified and accounted for?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. Compound quantitation/CRQLs				
Were the correct internal standard (IS), quantitation ion and relative response factor (RRF) used to quantitate the compound?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Tentatively identified compounds (TICs)				
Were the major ions (> 10 percent relative intensity) in the reference spectrum evaluated in sample spectrum?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Were relative intensities of the major ions within ± 20% between the sample and the reference spectra?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Did the raw data indicate that the laboratory performed a library search for all required peaks in the chromatograms (samples and blanks)?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XIV. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XV. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XVI. Field duplicates				
Field duplicate pairs were identified in this SDG.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Target compounds were detected in the field duplicates.	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XVII. Field blanks				
Field blanks were identified in this SDG.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Target compounds were detected in the field blanks.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

VALIDATION FINDINGS WORKSHEET

METHOD: GC/MS BNA (EPA SW 846 Method 8270)

A. Phenol**	P. Bis(2-chloroethoxy)methane	EE. 2,6-Dinitrotoluene	TT. Pentachlorophenol**	III. Benzo(a)pyrene**
B. Bis (2-chloroethyl) ether	Q. 2,4-Dichlorophenol**	FF. 3-Nitroaniline	UU. Phenanthrene	JJJ. Indeno(1,2,3-cd)pyrene
C. 2-Chlorophenol	R. 1,2,4-Trichlorobenzene	GG. Acenaphthene**	VV. Anthracene	KKK. Dibenz(a,h)anthracene
D. 1,3-Dichlorobenzene	S. Naphthalene	HH. 2,4-Dinitrophenol*	WW. Carbazole	LLL. Benzo(g,h,i)perylene
E. 1,4-Dichlorobenzene**	T. 4-Chloroaniline	II. 4-Nitrophenol*	XX. Di-n-butylphthalate	MMM. Bis(2-Chloroisopropyl)ether
F. 1,2-Dichlorobenzene	U. Hexachlorobutadiene**	JJ. Dibenzofuran	YY. Fluoranthene**	NNN. Aniline
G. 2-Methylphenol	V. 4-Chloro-3-methylphenol**	KK. 2,4-Dinitrotoluene	ZZ. Pyrene	OOO. N-Nitrosodimethylamine
H. 2,2'-Oxybis(1-chloropropane)	W. 2-Methylnaphthalene	LL. Diethylphthalate	AAA. Butylbenzylphthalate	PPP. Benzoic Acid
I. 4-Methylphenol	X. Hexachlorocyclopentadiene*	MM. 4-Chlorophenyl-phenyl ether	BBB. 3,3'-Dichlorobenzidine	QQQ. Benzyl alcohol
J. N-Nitroso-di-n-propylamine*	Y. 2,4,6-Trichlorophenol**	NN. Fluorene	CCC. Benzo(a)anthracene	RRR. Pyridine
K. Hexachloroethane	Z. 2,4,5-Trichlorophenol	OO. 4-Nitroaniline	DDD. Chrysene	SSS. Benzidine
L. Nitrobenzene	AA. 2-Chloronaphthalene	PP. 4,6-Dinitro-2-methylphenol	EEE. Bis(2-ethylhexyl)phthalate	TTT.
M. Isophorone	BB. 2-Nitroaniline	QQ. N-Nitrosodiphenylamine (1)**	FFF. Di-n-octylphthalate**	<i>Acetophenone</i>
N. 2-Nitrophenol**	CC. Dimethylphthalate	RR. 4-Bromophenyl-phenylether	GGG. Benzo(b)fluoranthene	UUU.
O. 2,4-Dimethylphenol	DD. Acenaphthylene	SS. Hexachlorobenzene	HHH. Benzo(k)fluoranthene	<i>1,2,4,5-Tetra(nobenzene)</i>

xxx. N-(hydroxymethyl)phthalimide. yyy. Phenyl sulfide. zzz. Phenyl disulfide
AAAA. 4-chlorophenyl sulfone
www. Benzenethiol
4-CH(nobenzenthio)

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

METHOD: GC/MS BNA (EPA SW 846 Method 8270)

The Relative Response Factor (RRF), average RRF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

$RRF = (A_x)(C_w)/(A_w)(C_x)$
 average RRF = sum of the RRF's/number of standards
 $\%RSD = 100 * (S/X)$
 A_x = Area of compound,
 C_x = Concentration of compound,
 S = Standard deviation of the RRFs, X = Mean of the RRFs
 A_w = Area of associated internal standard
 C_w = Concentration of internal standard
 S = Standard deviation of the RRFs, X = Mean of the RRFs

#	Standard ID	Calibration Date	Compound (Reference Internal Standard)	Reported		Recalculated		Reported		Recalculated	
				RRF (SD std)	RRF (SD std)	RRF (SD std)	Average RRF (Initial)	Average RRF (Initial)	%RSD	%RSD	
1	1CAZ	6/2/08	Phenol (1st internal standard)	1.87853	1.87853	1.85537	1.85537	1.070	1.070	1.070	1.070
			Naphthalene (2nd internal standard)	1.09438	1.09438	1.10901	1.10901	1.328	1.328	1.328	1.328
			Fluorene (3rd internal standard)	1.41778	1.41778	1.4229	1.4229	0.573	0.573	0.573	0.573
			Pentachlorophenol (4th internal standard)	0.20260	0.20260	0.19634	0.19634	10.255	10.255	10.255	10.255
			Bis(2-ethylhexyl)phthalate (5th internal standard)	0.90763	0.90763	0.86343	0.86343	9.524	9.524	9.524	9.524
			Benzo(a)pyrene (6th internal standard)	1.13808	1.13808	1.1182	1.1182	6.486	6.486	6.486	6.486
2	1CAZ	6/18/08	Phenol (1st internal standard)	0.51976	0.51976	0.51274	0.51274	0.71511	0.71511	0.71511	0.71511
			Naphthalene (2nd internal standard)	1.20177	1.20177	1.18223	1.18223	0.93662	0.93662	0.93662	0.93662
			Fluorene (3rd internal standard)								
			Pentachlorophenol (4th internal standard)								
			Bis(2-ethylhexyl)phthalate (5th internal standard)								
			Benzo(a)pyrene (6th internal standard)								
3	1CAZ	6/18/08	Phenol (1st internal standard)	1.60116	1.60116	1.57590	1.57590	2.64232	2.64232	2.64232	2.64232
			Naphthalene (2nd internal standard)	0.33910	0.33910	0.33062	0.33062	4.49540	4.49540	4.49540	4.49540
			Fluorene (3rd internal standard)	1.03639	1.03639	1.02385	1.02385	1.22192	1.22192	1.22192	1.22192
			Pentachlorophenol (4th internal standard)	0.38651	0.38651	0.36637	0.36637	8.75397	8.75397	8.75397	8.75397
			Bis(2-ethylhexyl)phthalate (5th internal standard)	0.39770	0.39770	0.39265	0.39265	2.58826	2.58826	2.58826	2.58826
			Benzo(a)pyrene (6th internal standard)								

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A-2
SDG #: See copy

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

Page: 1 of 1
Reviewer: [Signature]
2nd Reviewer: [Signature]

METHOD: GC/MS BNA (EPA SW 846 Method 8270)

The percent difference (%D) of the initial calibration average Relative Response Factors (RRFs) and the continuing calibration RRFs were recalculated for the compounds identified below using the following calculation:

% Difference = $100 * (\text{ave. RRF} - \text{RRF}) / \text{ave. RRF}$
 RRF = $(A_x) / (C_x) / (A_s) / (C_s)$
 Where: ave. RRF = initial calibration average RRF
 RRF = continuing calibration RRF
 A_x = Area of compound,
 C_x = Concentration of compound,
 A_s = Area of associated internal standard
 C_s = Concentration of internal standard

#	Standard ID	Calibration Date	Compound (Reference Internal Standard)	Average RRF (Initial)	Reported		Recalculated	
					RRF (CC)	%D	RRF (CC)	%D
1	VCA527	6/19/08	Phenol (1st internal standard)	1.85537	1.80162	2.89731	2.89731	2.89731
			Naphthalene (2nd internal standard)	1.10901	1.08712	1.97399	1.97399	1.97399
			Fluorene (3rd internal standard)	1.41229	1.40878	1.24855	1.24855	1.24855
			Pentachlorophenol (4th internal standard)	0.19634	0.20730	5.58529	5.58529	5.58529
			Bis(2-ethylhexyl)phthalate (5th internal standard)	0.86343	0.87788	0.97842	0.97842	0.97842
			Benzo(a)pyrene (6th internal standard)	1.11183	1.12694	1.30062	1.30062	1.30062
2	VCA528	6/19/08	Phenol (1st internal standard)	0.51574	0.51326	0.10062	0.10062	0.10062
			Naphthalene (2nd internal standard)	1.18223	1.20772	2.09666	2.09666	2.09666
			Fluorene (3rd internal standard)					
			Pentachlorophenol (4th internal standard)					
			Bis(2-ethylhexyl)phthalate (5th internal standard)					
			Benzo(a)pyrene (6th internal standard)					
3	VCA529	6/19/08	Phenol (1st internal standard)	1.57590	1.59157	0.99462	0.99462	0.99462
			Naphthalene (2nd internal standard)	0.33002	0.33954	2.88719	2.88719	2.88719
			Fluorene (3rd internal standard)	1.02385	1.01788	0.58319	0.58319	0.58319
			Pentachlorophenol (4th internal standard)	0.36637	0.38045	3.84416	3.84416	3.84416
			Bis(2-ethylhexyl)phthalate (5th internal standard)	0.39265	0.39958	1.76341	1.76341	1.76341
			Benzo(a)pyrene (6th internal standard)					

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A2
 SDG #: Secon

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd reviewer: [Signature]

METHOD: GC/MS Semivolatiles (EPA SW 846 Method 8270)

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: SF/SS * 100

Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 3

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Nitrobenzene-d5	50	34.9805	70	70	0
2-Fluorobiphenyl	✓	36.6753	73	73	↓
Terphenyl-d14	✓	33.4531	67	67	
Phenol-d5	75	53.9595	72	72	
2-Fluorophenol	↓	52.1505	70	70	
2,4,6-Tribromophenol	↓	59.7343	80	80	
2-Chlorophenol-d4					
1,2-Dichlorobenzene-d4					

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Nitrobenzene-d5					
2-Fluorobiphenyl					
Terphenyl-d14					
Phenol-d5					
2-Fluorophenol					
2,4,6-Tribromophenol					
2-Chlorophenol-d4					
1,2-Dichlorobenzene-d4					

Sample ID: _____

	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
Nitrobenzene-d5					
2-Fluorobiphenyl					
Terphenyl-d14					
Phenol-d5					
2-Fluorophenol					
2,4,6-Tribromophenol					
2-Chlorophenol-d4					
1,2-Dichlorobenzene-d4					

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

METHOD: GC/MS BNA (EPA SW 846 Method 8270)

The percent recoveries (%R) and Relative Percent Difference (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC - SC) / SA$ Where: SSC = Spiked sample concentration SC = Sample concentration
 SA = Spike added
 RPD = $|MSC - MSC| * 2 / (MSC + MSC)$ MSC = Matrix spike concentration MSDC = Matrix spike duplicate concentration

MS/MSD samples: 3170309

Compound	Spike Added		Sample Concentration	Spiked Sample Concentration		Matrix Spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalculated
Phenol	3480	3430	ND	2640	2400	76	76	70	70	9.4	9.5
N-Nitroso-di-n-propylamine				2840	2580	82	82	75	75	9.4	9.6
4-Chloro-3-methylphenol				2870	2670	83	83	78	78	7.1	7.2
Acenaphthene				2780	2590	80	80	75	75	7.0	7.1
Pentachlorophenol				2590	2410	75	75	70	70	7.4	7.2
Pyrene				2490	2340	72	72	68	68	6.0	6.2

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

METHOD: GC/MS BNA (EPA SW 846 Method 8270)

The percent recoveries (%R) and Relative Percent Difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SC/SA)$ Where: SSC = Spike concentration
SA = Spike added

RPD = $(LCS - LCSD) / 2 * (LCS + LCSD)$ LCSC = Laboratory control sample concentration LCSDC = Laboratory control sample duplicate concentration

LCS/LCSD samples: 8170309

Compound	Spike Added (MMS)		Spike Concentration		LCS		LCSD		Percent Recovery		RPD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc	Reported	Recalc	Reported	Recalc	Reported	Recalculated
Phenol	3330	NA	2370	NA	71	71						
N-Nitroso-di-n-propylamine			2570		77	77						
4-Chloro-3-methylphenol			2600		78	78						
Acenaphthene			2520		75	76						
Pentachlorophenol			2270		68	68						
Pyrene			2260		68	68						

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Chlorinated Pesticides
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-0DL
TSB-CJ-09-10**
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 5 soil samples and one water sample listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8081A for Chlorinated Pesticides.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section V.

Field duplicates are summarized in Section XIV.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. GC/ECD Instrument Performance Check

Instrument performance was acceptable unless noted otherwise under initial calibration and continuing calibration sections.

III. Initial Calibration

Initial calibration of single and multicomponent compounds was performed for the primary (quantitation) column and confirmation column as required by this method.

The percent relative standard deviations (%RSD) were less than or equal to 20.0% for all compounds.

Retention time windows were evaluated and considered technically acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

IV. Continuing Calibration

Continuing calibration was performed at required frequencies.

The percent differences (%D) of calibration factors in continuing standard mixtures were within the 15.0% QC limits with the following exceptions:

Date	Standard	Channel	Compound	%D	Associated Samples	Flag	A or P
6/19/08	KCAL133	A	Methoxychlor	15.4	TSB-CJ-09-0 TSB-CJ-09-10** TSB-CJ-09-OMS TSB-CJ-09-OMSD 8170319MB	J+ (all detects)	A

The percent differences (%D) of the second source calibration standard were less than or equal to 15.0% for all compounds.

The individual 4,4'-DDT and Endrin breakdowns (%BD) were less than or equal to 15.0%.

Retention times (RT) of all compounds in the calibration standards were within QC limits for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

V. Blanks

Method blanks were reviewed for each matrix as applicable. No chlorinated pesticide contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No chlorinated pesticide contaminants were found in this blank.

VI. Surrogate Spikes

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits with the following exceptions:

Sample	Column	Surrogate	%R (Limits)	Compound	Flag	A or P
TSB-CJ-09-0	Not specified	Decachlorobiphenyl	314 (61-137)	All TCL compounds	J+ (all detects)	A
8169189MB	Not specified	Tetrachloro-m-xylene	58 (72-135)	All TCL compounds	J- (all detects) UJ (all non-detects)	P

VII. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Although the MS/MSD percent recoveries (%R) and relative percent difference (RPD) were not within QC limits for one compound, the LCS percent recovery (%R) was within QC limits and no data were qualified.

VIII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) were within QC limits.

IX. Regional Quality Assurance and Quality Control

Not applicable.

X. Pesticide Cleanup Checks

a. Florisil Cartridge Check

Florisil cleanup was not required and therefore not performed in this SDG.

b. GPC Calibration

GPC cleanup was not required and therefore not performed in this SDG.

XI. Target Compound Identification

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XII. Compound Quantitation and Reported CRQLs

All compound quantitation and CRQLs were within validation criteria with the following exceptions:

Sample	Compound	Finding	Criteria	Flag	A or P
TSB-CJ-09-0	beta-BHC	Sample result exceeded calibration range.	Reported result should be within calibration range.	J (all detects)	A

The sample results for detected compounds from the two columns were within 40% percent difference (%D) with the following exceptions:

Sample	Compound	%D	Flag	A or P
TSB-CJ-09-10**	gamma-Chlordane	218.5	J (all detects)	A

Raw data were not evaluated for the samples reviewed by Level III criteria.

XIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

XIV. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Chlorinated Pesticides - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Methoxychlor	J+ (all detects)	A	Continuing calibration (%D)
F8F130140	TSB-CJ-09-0	All TCL compounds	J+ (all detects)	A	Surrogate spikes (%R)
F8F130140	TSB-CJ-09-0	beta-BHC	J (all detects)	A	Compound quantitation and CRQLs
F8F130140	TSB-CJ-09-10**	gamma-Chlordane	J (all detects)	A	Compound quantitation and CRQLs (%D)

**BRC Tronox Parcel C
Chlorinated Pesticides - Laboratory Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Chlorinated Pesticides - Field Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A3a
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC Chlorinated Pesticides (EPA SW 846 Method 8081A)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
II.	GC/ECD Instrument Performance Check	A	
III.	Initial calibration	A	PSD. 12
IV.	Continuing calibration/ICV	SW	LEV = 1570
V.	Blanks	A	
VI.	Surrogate spikes	SW	
VII.	Matrix spike/Matrix spike duplicates	SW	
VIII.	Laboratory control samples	A	LOG
IX.	Regional quality assurance and quality control	N	
Xa.	Florisil cartridge check	N	
Xb.	GPC Calibration	N	
XI.	Target compound identification	A	Not reviewed for Level III validation.
XII.	Compound quantitation and reported CRQLs	SW	Not reviewed for Level III validation.
XIII.	Overall assessment of data	A	
XIV.	Field duplicates	N	
XV.	Field blanks	ND	R = 1

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	8169189MB	21	W	31
2	TSB-CJ-09-0	S	12	8170319MB	22	S	32
3	TSB-CJ-09-ODL		13		23		33
4	TSB-CJ-09-10**		14		24		34
5	TSB-CJ-09-OMS		15		25		35
6	TSB-CJ-09-OMSD		16		26		36
7			17		27		37
8			18		28		38
9			19		29		39
10			20		30		40

VALIDATION FINDINGS WORKSHEET

METHOD: Pesticide/PCBs (EPASW 846 Method 8081/8082)

A. alpha-BHC	I. Dieldrin	Q. Endrin ketone	Y. Aroclor-1242	GG.
B. beta-BHC	J. 4,4'-DDE	R. Endrin aldehyde	Z. Aroclor-1248	HH.
C. delta-BHC	K. Endrin	S. alpha-Chlordane	AA. Aroclor-1254	II.
D. gamma-BHC	L. Endosulfan II	T. gamma-Chlordane	BB. Aroclor-1260	JJ.
E. Heptachlor	M. 4,4'-DDD	U. Toxaphene	CC. DB 608	KK.
F. Aldrin	N. Endosulfan sulfate	V. Aroclor-1016	DD. DB 1701	LL.
G. Heptachlor epoxide	O. 4,4'-DDT	W. Aroclor-1221	EE.	MM.
H. Endosulfan I	P. Methoxychlor	X. Aroclor-1232	FF.	NN.

Notes:

LDC #: 19191A3d
 SDG #: Secdown

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: GC HPLC

Validation Area	Yes	No	NA	Findings/Comments
Technical holding times:				
All technical holding times were met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Cooler temperature criteria was met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Initial calibration:				
Did the laboratory perform a 5 point calibration prior to sample analysis?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a linear fit used for evaluation? If yes, were all percent relative standard deviations (%RSD) < 20%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a curve fit used for evaluation? If Yes, what was the acceptance criteria used?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Did the initial calibration meet the curve fit acceptance criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the RT windows properly established?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IV. Continuing calibration:				
What type of continuing calibration calculation was performed? <input checked="" type="checkbox"/> %D or <input type="checkbox"/> %R	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a continuing calibration analyzed daily?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent differences (%D) < 15%.0 or percent recoveries 85-115%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all the retention times within the acceptance windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
V. Blanks:				
Was a method blank associated with every sample in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a method blank analyzed for each matrix and concentration?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VI. Surrogate spikes:				
Were all surrogate %R within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
If the percent recovery (%R) of one or more surrogates was outside QC limits, was a reanalysis performed to confirm %R?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
VII. Matrix spike/Matrix spike duplicate:				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a MS/MSD analyzed every 20 samples of each matrix?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VIII. Laboratory control samples:				
Was an LCS analyzed for this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

LDC #: 19191 D3a
 SDG #: see COM

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: 9
 2nd Reviewer: 4

Validation Area	Yes	No	NA	Findings/Comments
IX Regional Quality Assurance and Quality Control Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
X Target compound identification Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XI Compound quantitation/CRQLs Were the retention times of reported detects within the RT windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII System performance System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII Overall assessment of data Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIV Field duplicates Were field duplicate pairs identified in this SDG?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field duplicates?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XV Field blanks Were field blanks identified in this SDG?	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field blanks?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

LDC #: 1919, A39
 SDG #: Beccom

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 1 of 1
 Reviewer: g
 2nd Reviewer: r

METHOD: GC HPLC _____

The calibration Factor (CF), average CF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

- CF = A/C
- average CF = sum of the CF/number of standards
- %RSD = $100 \cdot (S/X)$
- A = Area of compound,
- C = Concentration of compound,
- S = Standard deviation of the CF
- X = Mean of the CFs

#	Standard ID	Calibration Date	Compound	Reported		Recalculated		Reported		Recalculated	
				CF (% std)	RSD	Average CF (Initial)	%RSD	Average CF (Initial)	%RSD		
1	1CA2	6/12/08	2,4'-DDE (ch A) ✓	37366840	37366844	373785260	33785260	1.30108	1.3011	203802778	2.78044
			F (ch A)	21121720	21121720	681332132	681332132	2.78044	2.7804	881332132	2.76188
2	1CA2	6/16/08	0 (✓)	282338600	282338600	301269612	301269612	112425	11124	380182886	2.83696
			F (ch B)	363591000	363591000	133202078	133202078	8.79750	8.7975		
3											
4											

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A39
 SDG #: See CDW

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC HPLC

The percent difference (%D) of the initial calibration average Calibration Factors (CF) and the continuing calibration CF were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \cdot (\text{ave. CF} - \text{CF}) / \text{ave. CF}$ Where: ave. CF = initial calibration average CF
 CF = continuing calibration CF
 A = Area of compound
 C = Concentration of compound

#	Standard ID	Calibration Date	Compound	Average CF (cal)/ CCV Conc.	Reported		Recalculated	
					CF/Conc. CCV	%D	CF/Conc. CCV	%D
1	KC4133	6/19/18	2,4-DDE (ch A) ↓ F (ch B) F (ch A)	0.025	0.0242	3.3	0.0242	3.3
					0.0248	0.8	0.0248	0.8
					0.0256	2.3	0.0256	2.3
2			0 ↓ F (ch B) D ↓		0.0283	13.1	0.0283	13.1
					0.0251	0.4	0.0251	0.4
					0.0269	7.4	0.0269	7.4
3								
4								

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

LDC #: 1991A3a
 SDG #: See column
 METHOD: 1 GC HPLC

Page: 1 of 1
 Reviewer: [Signature]
 2nd reviewer: [Signature]

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

Where: SF = Surrogate Found
 SS = Surrogate Spiked

% Recovery: SF/SS * 100

Sample ID: 4

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	
TMX	enB	0.020	0.01992	100	100	0
DEB	v	v	0.01705	85	85	0

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

METHOD: GC HPLC

The percent recoveries (%R) and relative percent differences (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

%Recovery = $100 * (SSC - SC) / SA$

Where

SSC = Spiked sample concentration

SC = Sample concentration

SA = Spike added

RPD = $\frac{((SSCMS - SSCMSD) * 2)}{(SSCMS + SSCMSD)} * 100$

MSD = Matrix spike duplicate

MS/MSD samples: 5/6

Compound	Spike Added (MS/MSD)		Spike Sample Concentration (MS/MSD)		Sample Conf. (MS/MSD)		Matrix spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD	MS	MSD	MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)												
Diesel (8015)												
Benzene (8021B)												
Methane (RSK-175)												
2,4-D (8151)												
Dinoseb (8151)												
Naphthalene (8310)												
Anthracene (8310)												
HMX (8330)												
2,4,6-Trinitrotoluene (8330)												
F	17.4	17.4	16.1	15.6	ND		92	92	90	90	3.1	3.2
0	↓	↓	23.2	22.4	6.6		96	95	91	91	3.8	3.5

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

METHOD: GC HPLC

The percent recoveries (%R) and Relative Percent difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 \times \frac{SSC-SC}{SSC-SA}$

Where: SSC = Spiked sample concentration
SA = Spike added

RPD = $100 \times \frac{SSC-LCS}{SSC}$

LCS = Laboratory control sample percent recovery

LCSD = Laboratory control sample duplicate percent recovery

LCS/LCSD samples: 8170319

Compound	Spike Added		Spiked Sample Concentration		LCS		LCSD		Percent Recovery		Percent Recovery		RPD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)														
Diesel (8015)														
Benzene (8021B)														
Methane (RSK-175)														
2,4-D (8151)														
Dinoseb (8151)														
Naphthalene (8310)														
Anthracene (8310)														
HMX (8330)														
2,4,6-Trinitrotoluene (8330)														
F	16.7	NA	15.1	NA	90	90								
D	17.0	✓	17.0	✓	102	102								

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Polychlorinated Biphenyls
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8082 for Polychlorinated Biphenyls.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section V.

Field duplicates are summarized in Section XIV.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. GC/ECD Instrument Performance Check

Instrument performance was acceptable unless noted otherwise under initial calibration and continuing calibration sections.

III. Initial Calibration

Initial calibration of multicomponent compounds were performed for the primary (quantitation) column as required by the method.

The percent relative standard deviations (%RSD) were less than or equal to 20.0% for all compounds.

Retention time windows were evaluated and considered technically acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

IV. Continuing Calibration

Continuing calibration was performed at required frequencies.

The percent differences (%D) of calibration factors in continuing standard mixtures were within the 15.0% QC limits.

The percent difference (%D) of the second source calibration standard were less than or equal to 15.0% for all compounds.

Retention times (RT) of all compounds in the calibration standards were within QC limits for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

V. Blanks

Method blanks were reviewed for each matrix as applicable. No polychlorinated biphenyl contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No polychlorinated biphenyl contaminants were found in this blank.

VI. Surrogate Spikes

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits with the following exceptions:

Sample	Column	Surrogate	%R (Limits)	Compound	Flag	A or P
TSB-CJ-09-0	Not specified	Decachlorobiphenyl	522 (57-150)	All TCL compounds	J+ (all detects)	A

VII. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

VIII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) were within QC limits.

IX. Regional Quality Assurance and Quality Control

Not applicable.

X. Pesticide Cleanup Checks

a. Florisil Cartridge Check

Florisil cleanup was not required and therefore not performed in this SDG.

b. GPC Calibration

GPC cleanup was not required and therefore not performed in this SDG.

XI. Target Compound Identification

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XII. Compound Quantitation and Reported CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

XIV. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Parcel C
Polychlorinated Biphenyls - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	TSB-CJ-09-0	All TCL compounds	J+ (all detects)	A	Surrogate spikes (%R)

**BRC Parcel C
Polychlorinated Biphenyls - Laboratory Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

**BRC Parcel C
Polychlorinated Biphenyls - Field Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A3b
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC Polychlorinated Biphenyls (EPA SW 846 Method 8082)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: <u>6/12/08</u>
II.	GC/ECD Instrument Performance Check	N	
III.	Initial calibration	A	
IV.	Continuing calibration/ICV	A	<u>ICV = 1570</u>
V.	Blanks	A	
VI.	Surrogate spikes	TW	
VII.	Matrix spike/Matrix spike duplicates	A	
VIII.	Laboratory control samples	A	<u>LCS</u>
IX.	Regional quality assurance and quality control	N	
Xa.	Florisil cartridge check	N	
Xb.	GPC Calibration	N	
XI.	Target compound identification	A	Not reviewed for Level III validation.
XII.	Compound quantitation and reported CRQLs	A	Not reviewed for Level III validation.
XIII.	Overall assessment of data	A	
XIV.	Field duplicates	N	
XV.	Field blanks	ND	<u>R = 1</u>

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	<u>8168237 MB</u>	21		31	
2	TSB-CJ-09-0	S	12	<u>8170314 MB</u>	22		32	
3	TSB-CJ-09-10**	✓	13		23		33	
4	RINSATE-2MS	W	14		24		34	
5	RINSATE-2MSD	✓	15		25		35	
6	TSB-CJ-09-0MS	S	16		26		36	
7	TSB-CJ-09-0MSD	✓	17		27		37	
8			18		28		38	
9			19		29		39	
10			20		30		40	

LDC #: 19191A36
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: GC HPLC

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times:				
All technical holding times were met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Cooler temperature criteria was met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
II. Initial calibration:				
Did the laboratory perform a 5 point calibration prior to sample analysis?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a linear fit used for evaluation? If yes, were all percent relative standard deviations (%RSD) < 20%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a curve fit used for evaluation? If Yes, what was the acceptance criteria used?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Did the initial calibration meet the curve fit acceptance criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the RT windows properly established?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
III. Continuing calibration:				
What type of continuing calibration calculation was performed? <u> </u> %D or %R	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a continuing calibration analyzed daily?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent differences (%D) < 15%.0 or percent recoveries 85-115%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all the retention times within the acceptance windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IV. Blanks:				
Was a method blank associated with every sample in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a method blank analyzed for each matrix and concentration?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
V. Surrogate spikes:				
Were all surrogate %R within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
If the percent recovery (%R) of one or more surrogates was outside QC limits, was a reanalysis performed to confirm %R?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VI. Matrix spike/Matrix spike duplicates:				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a MS/MSD analyzed every 20 samples of each matrix?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
VII. Laboratory control samples:				
Was an LCS analyzed for this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

LDC #: 199143b
 SDG #: see con

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IX. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
X. Target compound identification				
Were the retention times of reported detects within the RT windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Compound quantitation/CRQLs				
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIV. Field duplicates				
Were field duplicate pairs identified in this SDG?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field duplicates?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XV. Field blanks				
Were field blanks identified in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field blanks?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

VALIDATION FINDINGS WORKSHEET

METHOD: Pesticide/PCBs (EPASW 846 Method 8081/8082)

A. alpha-BHC	I. Dieldrin	Q. Endrin ketone	Y. Aroclor-1242	GG.
B. beta-BHC	J. 4,4'-DDE	R. Endrin aldehyde	Z. Aroclor-1248	HH.
C. delta-BHC	K. Endrin	S. alpha-Chlordane	AA. Aroclor-1254	II.
D. gamma-BHC	L. Endosulfan II	T. gamma-Chlordane	BB. Aroclor-1260	JJ.
E. Heptachlor	M. 4,4'-DDD	U. Toxaphene	CC. DB 608	KK.
F. Aldrin	N. Endosulfan sulfate	V. Aroclor-1016	DD. DB 1701	LL.
G. Heptachlor epoxide	O. 4,4'-DDT	W. Aroclor-1221	EE.	MM.
H. Endosulfan I	P. Methoxychlor	X. Aroclor-1232	FF.	NN.

Notes: _____

LDC #: 19191A-6
SDG #: See comments

VALIDATION FINDINGS WORKSHEET

Surrogate Recovery

Page: 1 of 1
Reviewer: 4
2nd Reviewer: 9

METHOD: GC HPLC

Are surrogates required by the method? Yes or No

Please see qualifications below for all questions answered "N". Not applicable questions are identified as "N/A".

N/A Were surrogates spiked into all samples and blanks?
 N/A Did all surrogate recoveries (%R) meet the QC limits?

#	Sample ID	Detector/Column	Surrogate Compound	%R (Limits)	Qualifications
	2	NS	DCB	522 (57-150)	1+ dots / A
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	
				()	

Surrogate Compound	Surrogate Compound	Surrogate Compound	Surrogate Compound	Surrogate Compound
A Chlorobenzene (CBZ)	G Octacosane	M Benzo(e)Pyrene	S 1-Chloro-3-Nitrobenzene	Y Tetrachloro-m-xylene
B 4-Bromofluorobenzene (BFB)	H Ortho-Terphenyl	N Terphenyl-D14	T 3,4-Dinitrotoluene	
C a,a,a-Trifluorotoluene	I Fluorobenzene (FBZ)	O Decachlorobiphenyl (DCB)	U Tripentyltin	
D Bromochlorobenzene	J n-Triacontane	P 1-methylnaphthalene	V Tri-n-propyltin	
E 1,4-Dichlorobutane	K Hexacosane	Q Dichlorophenyl Acetic Acid (DCAA)	W Tributyl Phosphate	
F 1,4-Difluorobenzene (DFB)	L Bromobenzene	R 4-Nitrophenol	X Triphenyl Phosphate	

LDC #: 1991A36
 SDG #: 201.com

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC ✓ HPLC _____

The calibration Factor (CF), average CF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

- CF = A/C
- average CF = sum of the CF/number of standards
- %RSD = $100 \cdot (S/X)$
- A = Area of compound,
- C = Concentration of compound,
- S = Standard deviation of the CF
- X = Mean of the CFs

#	Standard ID	Calibration Date	Compound	Reported		Recalculated		Reported		Recalculated	
				CF (SD std)	CF (SD std)	Average CF (initial)	Average CF (initial)	%RSD	%RSD		
1	10A ✓	5/21/08	BB (RX-c-post)	33154	33154	27977	27977	12.0	12.0		
			BB (V II)	45676	45676	39164	39164	9.58	9.58		
2											
3											
4											

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 191112b
 SDG #: See com

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

Page: 1 of 1
 Reviewer: SS
 2nd Reviewer: SS

METHOD: GC HPLC _____

The percent difference (%D) of the initial calibration average Calibration Factors (CF) and the continuing calibration CF were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \cdot (\text{ave. CF} - \text{CF}) / \text{ave. CF}$ Where: ave. CF = initial calibration average CF
 CF = A/C
 CF = continuing calibration CF
 A = Area of compound
 C = Concentration of compound

#	Standard ID	Calibration Date	Compound	Average CF (cal)/ CCV Conc.	Reported		Recalculated	
					CF/Conc. CCV	%D	CF/Conc. CCV	%D
1	PCA422	6/18/08	BB (cal A)	1000	1027.438	2.7	1027.40	2.7
2	PCA428	6/18/08	BB (cal A) V (cal B)	1000 1000	991.8768 1075.6662	0.8 7.6	992.0 1075.60	0.8 7.6
3								
4								

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

LDC #: 19191Aab
 SDG #: Se. equn
 METHOD: GC HPLC

Page: 1 of 1
 Reviewer: [Signature]
 2nd reviewer: [Signature]

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: $SF/SS * 100$
 Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 3

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	
<u>PCP</u>	<u>ch A</u>	<u>20.0</u>	<u>19.3366</u>	<u>97</u>	<u>97</u>	<u>0</u>

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

LDC #: *1919Azb*
 SDG #: *See com*

METHOD: GC HPLC

The percent recoveries (%R) and relative percent differences (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

$\%Recovery = 100 * (SSC - SC) / SA$ Where $SSC = \text{Spiked sample concentration}$ $SC = \text{Sample concentration}$
 $RPD = ((SSCMS - SSCMSD) * 2) / (SSCMS + SSCMSD) * 100$ $SA = \text{Spike added}$ $MSD = \text{Matrix spike duplicate}$
 $MS = \text{Matrix spike}$

MS/MSD samples: *6/7*

Compound	Spike Added <i>(173)</i>		Sample Comp. <i>(173)</i>	Spike Sample Concentration <i>(173)</i>		Matrix spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)											
Diesel (8015)											
Benzene (8021B)											
Methane (RSK-175)											
2,4-D (8151)											
Dinoseb (8151)											
Naphthalene (8310)											
Anthracene (8310)											
HMX (8330)											
2,4,6-Trinitrotoluene (8330)											
<i>AKB</i>	<i>173</i>	<i>174</i>	<i>ND</i>	<i>193</i>	<i>178</i>	<i>112</i>	<i>112</i>	<i>102</i>	<i>102</i>	<i>8.4</i>	<i>8.1</i>

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Laboratory Control Sample/Laboratory Control Sample Duplicate Results Verification

METHOD: ✓ GC HPLC

The percent recoveries (%R) and Relative Percent difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC-SC)/SA$ Where: SSC = Spiked sample concentration SC = Concentration
 SA = Spike added
 RPD = $100 * |SSCLCS - SSCLCSD| / (SSCLCS + SSCLCSD)$ LCS = Laboratory control sample percent recovery
 LCSLCS = Laboratory control sample duplicate percent recovery

LCS/LCSD samples: 8170315

Compound	Spike Added (<u>1715</u>)		Spiked Sample Concentration (<u>1715</u>)		LCS		LCSLCS	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.
	Percent Recovery		Percent Recovery		Reported	Recalc.	Reported	Recalc.
Gasoline (8015)								
Diesel (8015)								
Benzene (8021B)								
Methane (RSK-175)								
2,4-D (8151)								
Dinoseb (8151)								
Naphthalene (8310)								
Anthracene (8310)								
HMX (8330)								
2,4,6-Trinitrotoluene (8330)								
<u>BB</u>	<u>167</u>	<u>NA</u>	<u>178</u>	<u>NA</u>	<u>107</u>	<u>107</u>		

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Sample Calculation Verification

LDC #: 19994ab
 SDG #: 222000

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC HPLC

Y N N/A
Y N N/A

Were all reported results recalculated and verified for all level IV samples?
 Were all recalculated results for detected target compounds agree within 10% of the reported results?

Concentration = $\frac{(A)(Fv)(Df)}{(RF)(Vs \text{ or } Ws)(\%S/100)}$
 Example: Sample ID. B Compound Name ND

- A= Area or height of the compound to be measured
- Fv= Final Volume of extract
- Df= Dilution Factor
- RF= Average response factor of the compound in the initial calibration
- Vs= Initial volume of the sample
- Ws= Initial weight of the sample
- %S= Percent Solid

Concentration = _____

#	Sample ID	Compound	Reported Concentrations	Recalculated Results Concentrations	Qualifications

Comments: _____

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 7, 2008
Matrix: Soil/Water
Parameters: Metals
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and one water sample listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Methods 6010B, 6020, and 7000 for Metals. The metals analyzed were Aluminum, Antimony, Arsenic, Barium, Beryllium, Boron, Cadmium, Calcium, Chromium, Cobalt, Copper, Iron, Lead, Lithium, Magnesium, Manganese, Molybdenum, Mercury, Nickel, Niobium, Palladium, Phosphorus, Platinum, Potassium, Selenium, Silicon, Silver, Sodium, Strontium, Sulfur, Thallium, Tin, Titanium, Tungsten, Uranium, Vanadium, Zinc, and Zirconium.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review (October 2004) as there are no current guidelines for the methods stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blanks are summarized in Section III.

Field duplicates are summarized in Section XIII.

Samples indicated by a double asterisk on the front cover underwent a EPA Level IV review. A EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. Calibration

An initial calibration was performed.

The frequency and analysis criteria of the initial calibration verification (ICV) and continuing calibration verification (CCV) were met with the following exceptions:

Date	Lab. Reference/ID	Analyte	%R (Limits)	Associated Samples	Flag	A or P
6/25/08	CCV (22:30)	Thallium Uranium	113.4 (90-110) 115.8 (90-110)	All water samples in SDG F8F130140	J+ (all detects) J+ (all detects)	P

III. Blanks

Method blanks were reviewed for each matrix as applicable. No contaminant concentrations were found in the initial, continuing and preparation blanks with the following exceptions:

Method Blank ID	Analyte	Maximum Concentration	Associated Samples
PB (prep blank)	Antimony Iron	0.89 ug/L 21.5 ug/L	All water samples in SDG F8F130140
ICB/CCB	Antimony Cadmium Vanadium	1.3 ug/L 0.1 ug/L 2.7 ug/L	All water samples in SDG F8F130140
ICB/CCB	Antimony Thallium Tungsten Vanadium Lithium Mercury	1.3 ug/L 1.1 ug/L 1.5 ug/L 2.7 ug/L 8.0 ug/L 0.1 ug/L	All soil samples in SDG F8F130140

Sample concentrations were compared to concentrations detected in the method blanks as required by the QAPP. No sample data was qualified with the following exceptions:

Sample	Analyte	Reported Concentration	Modified Final Concentration
TSB-CJ-09-0	Tungsten	0.54 mg/Kg	1.0U mg/Kg
TSB-CJ-09-10**	Thallium Tungsten Mercury	0.40 mg/Kg 1.1 mg/Kg 21.2 ug/Kg	0.44U mg/Kg 1.1U mg/Kg 36.5U ug/Kg

Sample RINSATE-2 was identified as a rinsate. No metal contaminants were found in this blank with the following exceptions:

Rinsate ID	Sampling Date	Analyte	Concentration	Associated Samples
RINSATE-2	6/12/08	Calcium Iron Magnesium Sodium Strontium Thallium	48.2 ug/L 59.1 ug/L 6.1 ug/L 11.0 ug/L 0.80 ug/L 1.5 ug/L	All soil samples in SDG F8F130140

Sample concentrations were compared to concentrations detected in the field blanks as required by the QAPP. No sample data was qualified with the following exceptions:

Sample	Analyte	Reported Concentration	Modified Final Concentration
TSB-CJ-09-10**	Thallium	0.40 mg/Kg	0.44U mg/Kg

IV. ICP Interference Check Sample (ICS) Analysis

The frequency of analysis was met.

The criteria for analysis were met with the following exceptions:

ICS ID	Analyte	%R (Limits)	Associated Samples	Flag	A or P
ICSAB (6/17/08)	Sulfur	120.2 (80-120)	All water samples in SDG F8F130140	None	P

V. Matrix Spike Analysis

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits with the following exceptions:

Spike ID (Associated Samples)	Analyte	MS (%R) (Limits)	MSD (%R) (Limits)	RPD (Limits)	Flag	A or P
TSB-CJ-09-0MS/MSD (All soil samples in SDG F8F130140)	Silicon	393.7 (75-125)	361.5 (75-125)	-	J+ (all detects)	A
	Titanium	237.7 (75-125)	300.9 (75-125)	-	J+ (all detects)	
	Potassium	-	128.9 (75-125)	-	J+ (all detects)	
	Zinc	-	125.7 (75-125)	-	J+ (all detects)	
TSB-CJ-09-0MS/MSD (All soil samples in SDG F8F130140)	Magnesium	64.6 (75-125)	161.1 (75-125)	-	J (all detects) UJ (all non-detects)	A
TSB-CJ-09-0MS/MSD (All soil samples in SDG F8F130140)	Antimony	53.5 (75-125)	55.4 (75-125)	-	J- (all detects)	A
	Mercury	52.6 (75-125)	-	-	UJ (all non-detects)	
	Strontium	-	74.8 (75-125)	-		
	Niobium	42.1 (75-125)	46.5 (75-125)	-		

VI. Duplicate Sample Analysis

Duplicate (DUP) sample analyses were reviewed for each matrix as applicable.

VII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) were within QC limits with the following exceptions:

LCS ID	Analyte	%R (Limits)	Associated Samples	Flag	A or P
LCS	Palladium	81.0 (85-115)	All water samples in SDG F8F130140	J- (all detects) UJ (all non-detects)	P

VIII. Internal Standards (ICP-MS)

All internal standard percent recoveries (%R) were within QC limits for samples on which an EPA Level IV review was performed with the following exceptions:

Sample	Internal Standard	%R (Limits)	Analyte	Flag	A or P
TSB-CJ-09-10**	Scandium-45	129.434 (30-120)	Silicon Strontium	J (all detects) UJ (all non-detects) J (all detects) UJ (all non-detects)	A

Raw data were not evaluated for the samples reviewed by Level III criteria.

IX. Furnace Atomic Absorption QC

Graphite furnace atomic absorption was not utilized in this SDG.

X. ICP Serial Dilution

ICP serial dilution analysis was performed by the laboratory. The analysis criteria were met with the following exceptions:

Diluted Sample	Analyte	%D (Limits)	Associated Samples	Flag	A or P
TSB-GJ-08-10'L	Iron	10.4 (≤ 10)	All soil samples in SDG F8F130140	J (all detects)	A

XI. Sample Result Verification

All sample result verifications were acceptable for samples on which a EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

XII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

XIII. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Metals - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Analyte	Flag	A or P	Reason
F8F130140	RINSATE-2	Thallium Uranium	J+ (all detects) J+ (all detects)	P	Calibration (CCV %R)
F8F130140	RINSATE-2	Sulfur	None	P	ICP interference check sample analysis (%R)
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Silicon Titanium Potassium Zinc	J+ (all detects) J+ (all detects) J+ (all detects) J+ (all detects)	A	Matrix spike/Matrix spike duplicates (%R)
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Magnesium	J (all detects) UJ (all non-detects)	A	Matrix spike/Matrix spike duplicates (%R)
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Antimony Mercury Strontium Niobium	J- (all detects) UJ (all non-detects)	A	Matrix spike/Matrix spike duplicates (%R)
F8F130140	RINSATE-2	Palladium	J- (all detects) UJ (all non-detects)	P	Laboratory control samples (%R)
F8F130140	TSB-CJ-09-10**	Silicon Strontium	J (all detects) UJ (all non-detects) J (all detects) UJ (all non-detects)	A	Internal standards (%R)
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Iron	J (all detects)	A	ICP serial dilution (%D)

**BRC Tronox Parcel C
Metals - Laboratory Blank Data Qualification Summary - SDG F8F130140**

SDG	Sample	Analyte	Modified Final Concentration	A or P
F8F130140	TSB-CJ-09-0	Tungsten	1.0U mg/Kg	A
F8F130140	TSB-CJ-09-10**	Thallium Tungsten Mercury	0.44U mg/Kg 1.1U mg/Kg 36.5U ug/Kg	A

**BRC Tronox Parcel C
Metals - Field Blank Data Qualification Summary - SDG F8F130140**

SDG	Sample	Analyte	Modified Final Concentration	A or P
F8F130140	TSB-CJ-09-10**	Thallium	0.44U mg/Kg	A

LDC #: 19191A4
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: MY
 2nd Reviewer: 9

METHOD: Metals (EPA SW 846 Method 6020/6010B/7000)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
II.	Calibration	SW	
III.	Blanks	SW	
IV.	ICP Interference Check Sample (ICS) Analysis	SW	
V.	Matrix Spike Analysis	SW	3MS/MSD
VI.	Duplicate Sample Analysis	N	
VII.	Laboratory Control Samples (LCS)	SW	LCS
VIII.	Internal Standard (ICP-MS)	SW	N.T. reviewed for level 3
IX.	Furnace Atomic Absorption QC	N	N.T. utilized
X.	ICP Serial Dilution	SW	
XI.	Sample Result Verification	A	Not reviewed for Level III validation.
XII.	Overall Assessment of Data	A	
XIII.	Field Duplicates	N	
XIV.	Field Blanks	SW	R=1

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	A2	11	PB	21		31
2	TSB-CJ-09-0	S ₂ -1	12		22		32
3	TSB-CJ-09-10**		13		23		33
4	TSB-CJ-09-0MS		14		24		34
5	TSB-CJ-09-0MSD		15		25		35
6			16		26		36
7			17		27		37
8			18		28		38
9			19		29		39
10			20		30		40

Notes: _____

LDC #: 19191A4
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: MY
 2nd Reviewer: CV

Method: Metals (EPA SW 846 Method 6010/7000/6020)

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	✓			
Cooler temperature criteria was met.	✓			
II. Calibration				
Were all instruments calibrated daily, each set-up time?	✓			
Were the proper number of standards used?	✓			
Were all initial and continuing calibration verification %Rs within the 90-110% (80-120% for mercury and 85-115% for cyanide) QC limits?		✓		
Were all initial calibration correlation coefficients > 0.995? (Level IV only)	✓			
III. Blanks				
Was a method blank associated with every sample in this SDG?	✓			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	✓			
IV. ICP Interference Check Sample				
Were ICP interference check samples performed daily?	✓			
Were the AB solution percent recoveries (%R) with the 80-120% QC limits?		✓		
IV. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and duplicate (DUP) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD or MS/DUP. Soil / Water.	✓			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the 75-125 QC limits? If the sample concentration exceeded the spike concentration by a factor of 4 or more, no action was taken.		✓		
Were the MS/MSD or duplicate relative percent differences (RPD) ≤ 20% for waters and ≤ 35% for soil samples? A control limit of +/- RL (+/-2X RL for soil) was used for samples that were ≤ 5X the RL, including when only one of the duplicate sample values were < 5X the RL.		✓		
V. Laboratory control samples				
Was an LCS analyzed for this SDG?	✓			
Was an LCS analyzed per extraction batch?	✓			
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the 80-120% QC limits for water samples and laboratory established QC limits for soils?		✓		
VI. Furnace Atomic Absorption QC				
If MSA was performed, was the correlation coefficients > 0.995?			✓	
Do all applicable analyses have duplicate injections? (Level IV only)			✓	
For sample concentrations > RL, are applicable duplicate injection RSD values < 20%? (Level IV only)			✓	
Were analytical spike recoveries within the 85-115% QC limits?			✓	

LDC #: 19/91 A/C
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: MM
 2nd Reviewer: 9

Validation Area	Yes	No	NA	Findings/Comments
VII: ICP Serial Dilution				
Was an ICP serial dilution analyzed if analyte concentrations were > 50X the IDL?	<input checked="" type="checkbox"/>			> 100x MOC for 20/1/13
Were all percent differences (%Ds) < 10%?		<input checked="" type="checkbox"/>		
Was there evidence of negative interference? If yes, professional judgement will be used to qualify the data.		<input checked="" type="checkbox"/>		
VIII: Internal Standards (EPA SW-846 Method 8020)				
Were all the percent recoveries (%R) within the 30-120% of the intensity of the internal standard in the associated initial calibration?	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
If the %Rs were outside the criteria, was a reanalysis performed?		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
IX: Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?			<input checked="" type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?			<input checked="" type="checkbox"/>	
X: Sample Result Verification				
Were RLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>			
XI: Overall Assessment of Field				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>			
XII: Field Duplicates				
Field duplicate pairs were identified in this SDG.		<input checked="" type="checkbox"/>		
Target analytes were detected in the field duplicates.			<input checked="" type="checkbox"/>	
XIII: Field Blanks				
Field blanks were identified in this SDG.	<input checked="" type="checkbox"/>			
Target analytes were detected in the field blanks.	<input checked="" type="checkbox"/>			

LDC #: 19191AY
 SDG #: See cover

VALIDATION FINDINGS WORKSHEET
Sample Specific Element Reference

Page: 1 of 1
 Reviewer: mm
 2nd reviewer: q

All circled elements are applicable to each sample.

Sample ID	Matrix	Target Analyte List (TAL)
1-3	As/soil	Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
m4-5	soil	Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
1-3	As/soil	Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
m4-5	soil	Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,
		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Li, S, Zr,

Analysis Method		
ICP		Li, S,
ICP-MS		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si,
ICP-MS		Nb, Pd, P, Pt, Sn, Sr, Ti, W, U, Zr,
GFAA		Al, Sb, As, Ba, Be, Cd, Ca, Cr, Co, Cu, Fe, Pb, Mg, Mn, Hg, Ni, K, Se, Ag, Na, Ti, V, Zn, Mo, B, Si, CN,

Comments: Mercury by CVAA if performed
 Nb: Niobium, Pd: Palladium, P: Phosphorus, Pt: Platinum, S: Sulfur, W: Tungsten, U: Uranium, Zr: Zirconium

LDC #: 19191A4
 SDG #: See cover

VALIDATION FINDINGS WORKSHEET
Initial and Continuing Calibration Calculation Verification

Page: 1 of 1
 Reviewer: ML
 2nd Reviewer: [Signature]

METHOD: Trace Metals (EPA SW 846 Method 6010/6020/7000)

An initial and continuing calibration verification percent recovery (%R) was recalculated for each type of analysis using the following formula:

%R = $\frac{\text{Found} \times 100}{\text{True}}$ Where, Found = concentration (in ug/L) of each analyte measured in the analysis of the ICV or CCV solution
 True = concentration (in ug/L) of each analyte in the ICV or CCV source

Standard ID	Type of Analysis	Element	Found (ug/L)	True (ug/L)	Recalculated		Reported		Acceptable (Y/N)
					%R	%R	%R	%R	
ICV	ICP (Initial calibration)	Li	4067	4000	101.7	101.7	101.7	101.7	Y
	GFAA (Initial calibration)								
ICV	CVAA (Initial calibration)	Hg	2.33	2.50	93.2	93.2	93.2	93.2	Y
CCV	ICP (Continuing calibration)	S	52670	50000	105.3	105.3	105.3	105.3	↓
	GFAA (Continuing calibration)								
CCV	CVAA (Continuing calibration)	Hg	4.89	5.0	97.8	97.8	97.8	97.8	Y
ICV	ICP/MS (Initial calibration)	Mn	1018.9	1000	101.9	101.9	101.9	101.9	↓
CCV	ICP/MS (Continuing calibration)	Sr	1072	1000	107.2	107.2	107.2	107.2	↓

Comments: Refer to Calibration Verification findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 1919/AN
 SDG #: Self cover

Page: 1 of 1
 Reviewer: AM
 2nd Reviewer: Q

VALIDATION FINDINGS WORKSHEET
Level IV Recalculation Worksheet

METHOD: Trace Metals (EPA SW 846 Method 6010/7000)

Percent recoveries (%R) for an ICP interference check sample, a laboratory control sample and a matrix spike sample were recalculated using the following formula:

$$\%R = \frac{\text{Found}}{\text{True}} \times 100$$

Where, Found = Concentration of each analyte measured in the analysis of the sample. For the matrix spike calculation,
 Found = SSR (spiked sample result) - SR (sample result).
 True = Concentration of each analyte in the source.

A sample and duplicate relative percent difference (RPD) was recalculated using the following formula:

$$RPD = \frac{|S-D|}{(S+D)/2} \times 100$$

Where, S = Original sample concentration
 D = Duplicate sample concentration

An ICP serial dilution percent difference (%D) was recalculated using the following formula:

$$\%D = \frac{|I-SDR|}{I} \times 100$$

Where, I = Initial Sample Result (mg/L)
 SDR = Serial Dilution Result (mg/L) (Instrument Reading x 5)

Sample ID	Type of Analysis	Element	Found / S / I (units)	True / D / SDR (units)	Recalculated		Acceptable (Y/N)
					%R / RPD / %D	Reported %R / RPD / %D	
TESAP	ICP interference check	Ag	19.106	20	95.5	95.5	Y
LC7	Laboratory control sample	Ba	488	520	93.8	93.9	
4	Matrix spike	Li (SSR-SR)	105.1	104.3	100.8	100.8	
4/5	Duplicate	Cu	24.5	22.5	8.5	8.5	
TSP-6J-08-101	ICP serial dilution	Ca	67207	62288	9.9	9.9	Y

Comments: Refer to appropriate worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191 A40
 SDG #: see cover

VALIDATION FINDINGS WORKSHEET
Sample Calculation Verification

Page: 1 of 2
 Reviewer: my
 2nd reviewer: [Signature]

METHOD: Trace Metals (EPA SW 846 Method 6010/7000)

Please see qualifications below for all questions answered "N". Not applicable questions are identified as "N/A".

- Y N N/A Have results been reported and calculated correctly?
- Y N N/A Are results within the calibrated range of the instruments and within the linear range of the ICP?
- Y N N/A Are all detection limits below the CRDL?

Detected analyte results for 3 were recalculated and verified using the following equation:

$$\text{Concentration} = \frac{(\text{RD})(\text{FV})(\text{Dil})}{(\text{In. Vol.})(\%S)}$$

Recalculation:

$$B = \frac{18093 \mu\text{g/L} \times 0.1 \text{ L} \times 2}{0.58 \times 0.9132} = 79163 \mu\text{g/kg}$$

- RD = Raw data concentration
- FV = Final volume (ml)
- In. Vol. = Initial volume (ml) or weight (G)
- Dil = Dilution factor
- %S = Decimal percent solids

Sample ID	Analyte	Reported Concentration (µg/kg)	Calculated Concentration (µg/kg)	Acceptable (Y/N)
3	Al	9530	9530	Y
	As	10.6	10.6	
	Ba	91.6	91.6	
	Be	0.58	0.58	
	B	1.9	1.9	
	Cd	0.083	0.083	
	Ca	30100	30100	
	Cr	12.1	12.1	
	Co	6.7	6.7	
	Cu	13.8	13.8	
	Fe	13000	13000	
	Pb	8.3	8.3	
	Mg	9800	9800	
	Mn	312	312	
	Mo	0.45	0.45	
	Ni	14.1	14.1	
	Pd	0.57	0.57	
	P	740	740	
	K	1770	1770	
	Si	523	523	
	Ag	0.15	0.15	
	Na	1820	1820	✓

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 7, 2008
Matrix: Soil/Water
Parameters: Wet Chemistry
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2DUP
TSB-CJ-09-0MS
TSB-CJ-09-0MSD
TSB-CJ-09-0DUP

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 5 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA Method 300.0 for Bromide, Bromine, Chlorate, Chloride, Chlorine, Fluoride, Nitrate as Nitrogen, Nitrite as Nitrogen, Orthophosphate as Phosphorus, and Sulfate and EPA Method 1664A and EPA SW 846 Method 9071B for Oil & Grease.

The review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review (October 2004) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section III.

Field duplicates are summarized in Section IX.

Samples indicated by a double asterisk on the front cover underwent a EPA Level IV review. A EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. Calibration

a. Initial Calibration

All criteria for the initial calibration of each method were met.

b. Calibration Verification

Calibration verification frequency and analysis criteria were met for each method when applicable.

III. Blanks

Method blanks were reviewed for each matrix as applicable. No contaminant concentrations were found in the initial, continuing and preparation blanks with the following exceptions:

Method Blank ID	Analyte	Concentration	Associated Samples
CCB1	Orthophosphate as P	0.102 mg/L	TSB-CJ-09-0
CCB2	Orthophosphate as P	0.126 mg/L	TSB-CJ-09-10**

Sample concentrations were compared to concentrations detected in the method blanks as required by the QAPP. No sample data was qualified.

Sample RINSATE-2 was identified as a rinsate. No contaminant concentrations were found in this blank with the following exceptions:

Rinsate ID	Sampling Date	Analyte	Concentration	Associated Samples
RINSATE-2	6/12/08	Sulfate	0.11 mg/L	All soil samples in SDG F8F130140

Sample concentrations were compared to concentrations detected in the field blanks as required by the QAPP. No sample data was qualified.

IV. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits with the following exceptions:

Spike ID (Associated Samples)	Analyte	MS (%R) (Limits)	MSD (%R) (Limits)	RPD (Limits)	Flag	A or P
TSB-CJ-09-0MS/MSD (All soil samples in SDG F8F130140)	Oil & grease	63 (75-125)	63 (75-125)	-	J- (all detects) UJ (all non-detects)	A

V. Duplicates

Duplicate (DUP) sample analyses were reviewed for each matrix as applicable. Results were within QC limits.

VI. Laboratory Control Samples

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

VII. Sample Result Verification

All sample result verifications were acceptable for samples on which a EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

IX. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Wet Chemistry - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Analyte	Flag	A or P	Reason
F8F130140	TSB-CJ-09-0 TSB-CJ-09-10**	Oil & grease	J- (all detects) UJ (all non-detects)	A	Matrix spike/Matrix spike duplicates (%R)

**BRC Tronox Parcel C
Wet Chemistry - Laboratory Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Wet Chemistry - Field Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A6
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: (Analyte) Bromide, Bromine, Chlorate, Chloride, Chlorine, Fluoride, Nitrate, Nitrite, Orthophosphate-P, Sulfate (EPA Method 300.0), O & G (EPA SW846 Method 9071B/EPA 1664A)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
IIa.	Initial calibration	A	
IIb.	Calibration verification	A	
III.	Blanks	SW	
IV	Matrix Spike/Matrix Spike Duplicates	SW	MS/MSD/DUP
V	Duplicates	A	
VI.	Laboratory control samples	A	LCs/LCSD
VII.	Sample result verification	A	Not reviewed for Level III validation.
VIII.	Overall assessment of data	A	
IX.	Field duplicates	N	
X	Field blanks	SW	R=1

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	A2	11		21		31	
2	TSB-CJ-09-0	Soil	12		22		32	
3	TSB-CJ-09-10**	↓	13		23		33	
4	RINSATE-2MS	A2	14		24		34	
5	RINSATE-2DUP	↓	15		25		35	
6	TSB-CJ-09-0MS	Soil	16		26		36	
7	TSB-CJ-09-0MSD	↓	17		27		37	
8	TSB-CJ-09-0DUP	↓	18		28		38	
9	MS		19		29		39	
10			20		30		40	

Notes: _____

LDC #: 19191A6
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: WEM
 2nd Reviewer: ✓

Method: Inorganics (EPA Method See cover)

Validation Area	Yes	No	NA	Findings/Comments
I. Technical Holding Times				
All technical holding times were met.	✓			
Cooler temperature criteria was met.	✓			
II. Calibration				
Were all instruments calibrated daily, each set-up time?	✓			
Were the proper number of standards used?	✓			
Were all initial calibration correlation coefficients > 0.995?	✓			
Were all initial and continuing calibration verification %Rs within the 90-110% QC limits?	✓			
Were titrant checks performed as required? (Level IV only)			✓	
Were balance checks performed as required? (Level IV only)	✓			
III. Blanks				
Was a method blank associated with every sample in this SDG?	✓			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	✓			
IV. Matrix Spike and Duplicate				
Were a matrix spike (MS) and duplicate (DUP) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD or MS/DUP. Soil / Water.	✓			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the 75-125 QC limits? If the sample concentration exceeded the spike concentration by a factor of 4 or more, no action was taken.		✓		
Were the MS/MSD or duplicate relative percent differences (RPD) ≤ 20% for waters and ≤ 35% for soil samples? A control limit of < CRDL (≤ 2X CRDL for soil) was used for samples that were ≤ 5X the CRDL, including when only one of the duplicate sample values were < 5X the CRDL.	✓			
V. Laboratory Control Samples				
Was an LCS analyzed for this SDG?	✓			
Was an LCS analyzed per extraction batch?	✓			
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the 80-120% (85-115% for Method 300.0) QC limits?	✓			
VI. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?			✓	
Were the performance evaluation (PE) samples within the acceptance limits?			✓	

LDC #: 19191A6
 SDG #: *See cover*

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: *MM*
 2nd Reviewer: *[Signature]*

Validation Area	Yes	No	NA	Findings/Comments
VII. Sample Result Verification				
Were RLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were detection limits < RL?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Overall assessment of data was found to be acceptable.				
Field duplicate pairs were identified in this SDG.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Target analytes were detected in the field duplicates.	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Field blanks were identified in this SDG.				
Target analytes were detected in the field blanks.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

LDC #: 1919166

SDG #: See cover

Validatin Findings Worksheet
Initial and Continuing Calibration Calculation Verification

Page: 1 of 1
Reviewer: MV
2nd Reviewer: [Signature]

Method: Inorganics, Method See cover

The correlation coefficient (r) for the calibration of ClO_3 was recalculated. Calibration date: 6/18/08

An initial or continuing calibration verification percent recovery (%R) was recalculated for each type of analysis using the following formula:

$\%R = \frac{\text{Found} \times 100}{\text{True}}$
Where, Found = concentration of each analyte measured in the analysis of the ICV or CCV solution
True = concentration of each analyte in the ICV or CCV source

Type of analysis	Analyte	Standard	Conc. (ug/L)	Area	Recalculated		Reported		Acceptable (Y/N)
					r or r ²	r or r ²			
Initial calibration	ClO3	s1	500	0.034	0.99996	0.99991			Y
		s2	2000	0.151					
		s3	4000	0.317					
		s4	10000	0.777					
		s5	20000	1.586					
Calibration verification	ClO3	4	2,851		96.3		NR		Y
Calibration verification	0-1000	8	8,002		100.02		100.03		Y
Calibration verification	100-11	0.160	0,1634		102.13		102.14		Y

Comments: Refer to Calibration Verification findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A6
 SDG #: see cover

VALIDATION FINDINGS WORKSHEET
Level IV Recalculation Worksheet

Page: 1 of 1
 Reviewer: mm
 2nd Reviewer: [Signature]

METHOD: Inorganics, Method see cover

Percent recoveries (%R) for a laboratory control sample and a matrix spike sample were recalculated using the following formula:

$$\%R = \frac{\text{Found}}{\text{True}} \times 100$$
 Where, Found = concentration of each analyte measured in the analysis of the sample. For the matrix spike calculation, Found = SSR (spiked sample result) - SR (sample result).
 True = concentration of each analyte in the source.

A sample and duplicate relative percent difference (RPD) was recalculated using the following formula:

$$RPD = \frac{|S-D|}{(S+D)/2} \times 100$$
 Where, S = Original sample concentration
 D = Duplicate sample concentration

Sample ID	Type of Analysis	Element	Found / S (units)	True / D (units)	Recalculated		Acceptable (Y/N)
					%R / RPD	%R / RPD	
Lcs	Laboratory control sample	OTG	1250	1330	94	94	Y
6	Matrix spike sample	BY	(SSR-SR) 9.98 20.9	20.9	96	96	Y
8	Duplicate sample	CL	51.755	51.5722	0.35	0.35	Y

Comments: Refer to appropriate worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Gasoline Range Organics
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8015B for Gasoline Range Organics.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section III.

Field duplicates are summarized in Section IX.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. Calibration

a. Initial Calibration

Initial calibration of compounds was performed as required by the method.

The percent relative standard deviations (%RSD) of calibration factors for compounds were less than 20.0% .

b. Calibration Verification

Calibration verification was performed at required frequencies. The percent differences (%D) of amounts in continuing standard mixtures were within the 15.0% QC limits.

The percent differences (%D) of the second source calibration standard were less than or equal to 15.0% for all compounds.

III. Blanks

Method blanks were reviewed for each matrix as applicable. No gasoline range organic contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No gasoline range organic contaminants were found in this blank.

IV. Accuracy and Precision Data

a. Surrogate Recovery

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits.

b. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

c. Laboratory Control Samples

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

V. Target Compound Identification

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VI. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VII. System Performance

The system performance was acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

IX. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Gasoline Range Organics - Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Gasoline Range Organics - Laboratory Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Gasoline Range Organics - Field Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A7
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/15/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC Gasoline Range Organics (EPA SW846 Method 8015B)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: <u>6/12/08</u>
IIa.	Initial calibration	A	
IIb.	Calibration verification/ICV	A	<u>ICV = 15%</u>
III.	Blanks	A	
IVa.	Surrogate recovery	A	
IVb.	Matrix spike/Matrix spike duplicates	A	
IVc.	Laboratory control samples	A	<u>LCS 7</u>
V.	Target compound identification	A	Not reviewed for Level III validation.
VI.	Compound Quantitation and CRQLs	A	Not reviewed for Level III validation.
VII.	System Performance	A	Not reviewed for Level III validation.
VIII.	Overall assessment of data	A	
IX.	Field duplicates	N	
X.	Field blanks	ND	<u>E = 1</u>

Note: A = Acceptable ND = No compounds detected D = Duplicate
 N = Not provided/applicable R = Rinsate TB = Trip blank
 SW = See worksheet FB = Field blank EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	<u>8168739MB</u>	21		31
2	TSB-CJ-09-0	S	12	<u>8168741MB</u>	22	<u>S</u>	32
3	TSB-CJ-09-10**	↓	13		23		33
4	RINSATE-2MS	W	14		24		34
5	RINSATE-2MSD	↓	15		25		35
6	TSB-CJ-09-0MS	S	16		26		36
7	TSB-CJ-09-0MSD	↓	17		27		37
8			18		28		38
9			19		29		39
10			20		30		40

Notes: _____

LDC #: 19191A7
 SDG #: SecDown

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: GC HPLC

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	/			
Cooler temperature criteria was met.	/			
II. Initial calibration				
Did the laboratory perform a 5 point calibration prior to sample analysis?	/			
Was a linear fit used for evaluation? If yes, were all percent relative standard deviations (%RSD) < 20%?	/			
Was a curve fit used for evaluation? If Yes, what was the acceptance criteria used?			/	
Did the initial calibration meet the curve fit acceptance criteria?	/			
Were the RT windows properly established?	/			
III. Continuing calibration				
What type of continuing calibration calculation was performed? <u> </u> %D or %R	/			
Was a continuing calibration analyzed daily?	/			
Were all percent differences (%D) < 15%.0 or percent recoveries 85-115%?	/			
Were all the retention times within the acceptance windows?	/			
IV. Blanks				
Was a method blank associated with every sample in this SDG?	/			
Was a method blank analyzed for each matrix and concentration?	/			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.			/	
V. Surrogate spikes				
Were all surrogate %R within the QC limits?	/			
If the percent recovery (%R) of one or more surrogates was outside QC limits, was a reanalysis performed to confirm %R?			/	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?			/	
VI. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	/			
Was a MS/MSD analyzed every 20 samples of each matrix?	/			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	/			
VII. Laboratory control samples				
Was an LCS analyzed for this SDG?	/			
Was an LCS analyzed per extraction batch?	/			

LDC #: 19191AT
 SDG #: 2000WY

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IX. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
X. Target compound identification				
Were the retention times of reported detects within the RT windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Compound quantitation/CRQLs				
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIV. Field duplicates				
Were field duplicate pairs identified in this SDG?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field duplicates?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XV. Field blanks				
Were field blanks identified in this SDG?	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field blanks?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

LDC #: 1919A7

SDG #: See below

VALIDATION FINDINGS WORKSHEET Initial Calibration Calculation Verification

Page: 1 of 1

Reviewer: _____

2nd Reviewer: _____

METHOD: GC HPLC _____

The calibration Factor (CF), average CF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

- CF = A/C
- average CF = sum of the CF/number of standards
- %RSD = $100 * (S/X)$
- A = Area of compound,
- C = Concentration of compound,
- S = Standard deviation of the CF
- X = Mean of the CFs

#	Standard ID	Calibration Date	Compound	Reported		Recalculated		Reported		Recalculated	
				CF (0.1% std)	CF (0.1% std)	Average CF (initial)	Average CF (initial)	%RSD	%RSD		
1	<u>10A2</u>	<u>5/27/08</u>	<u>FRD</u>	<u>18352700</u>	<u>18352700</u>	<u>17182732</u>	<u>17182732</u>	<u>3.915</u>	<u>3.915</u>		
2											
3											
4											

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

METHOD: GC HPLC _____

The percent difference (%D) of the initial calibration average Calibration Factors (CF) and the continuing calibration CF were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \cdot (\text{ave. CF} - \text{CF}) / \text{ave. CF}$ Where: ave. CF = initial calibration average CF
 CF = continuing calibration CF
 A = Area of compound
 C = Concentration of compound

#	Standard ID	Calibration Date	Compound	Average CF (Ical)/ CCV Conc.	Reported		Recalculated	
					CF/Conc. CCV	%D	CF/Conc. CCV	%D
1	LCAL-100B SPD	6/16/18		1.0	1.0360	3.6	1.0360	3.6
2								
3								
4								

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 1191A7
 SDG #: 200000

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

Page: 6 of 7
 Reviewer: [Signature]
 2nd reviewer: [Signature]

METHOD: VGC HPLC

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: SF/SS * 100
 Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 3

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
TFT	AS	0.04	0.03592	90	90	0

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

LDC #: 199A7
 SDG #: 2200W

METHOD: GC HPLC

The percent recoveries (%R) and relative percent differences (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

$\% \text{Recovery} = 100 * (\text{SSC} - \text{SC}) / \text{SA}$ Where $\text{SSC} = \text{Spiked sample concentration}$ $\text{SC} = \text{Sample concentration}$
 $\text{RPD} = \frac{((\text{SSCMS} - \text{SSCMSD}) * 2) / (\text{SSCMS} + \text{SSCMSD}) * 100}{100}$ $\text{SA} = \text{Spike added}$ $\text{MSD} = \text{Matrix spike duplicate}$
 $\text{MS} = \text{Matrix spike}$

MS/MSD samples: 6/7

Compound	Spike Added (MS/MSD)		Sample Conc. (MS/MSD)	Spike Sample Concentration (MS/MSD)		Matrix spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)	1.04	1.04	ND	0.95	0.958	90	90	90	90	0.30	0.30
Diesel (8015)											
Benzene (8021B)											
Methane (RSK-175)											
2,4-D (8151)											
Dinoseb (8151)											
Naphthalene (8310)											
Anthracene (8310)											
HMX (8330)											
2,4,6-Trinitrotoluene (8330)											

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

METHOD: GC HPLC

The percent recoveries (%R) and Relative Percent difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC-SC)/SA$ Where: SSC = Spiked sample concentration SC = Concentration
 SA = Spike added
 RPD = $100 * |SSCLCS - SSCLCSD| / (SSCLCS + SSCLCSD)$ LCS = Laboratory control sample percent recovery LCSD = Laboratory control sample duplicate percent recovery

LCS/LCSD samples: 8168141

Compound	Spike Added (mg/L)		Spiked Sample Concentration (mg/L)		LCS Percent Recovery		LCSD Percent Recovery		LCS/LCSD RPD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)	1.0	1.0	0.957	0.918	95	95	92	92	3.9	3.9
Diesel (8015)										
Benzene (8021B)										
Methane (RSK-175)										
2,4-D (8151)										
Dinoseb (8151)										
Naphthalene (8310)										
Anthracene (8310)										
HMX (8330)										
2,4,6-Trinitrotoluene (8330)										

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Diesel Range Organics
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8015B for Diesel Range Organics.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section III.

Field duplicates are summarized in Section IX.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. Calibration

a. Initial Calibration

Initial calibration of compounds was performed as required by the method.

The percent relative standard deviations (%RSD) of calibration factors for compounds were less than 20.0% .

b. Calibration Verification

Calibration verification was performed at required frequencies. The percent differences (%D) of amounts in continuing standard mixtures were within the 15.0% QC limits.

The percent differences (%D) of the second source calibration standard were less than or equal to 15.0% for all compounds.

III. Blanks

Method blanks were reviewed for each matrix as applicable. No diesel range organic contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No diesel range organic contaminants were found in this blank.

IV. Accuracy and Precision Data

a. Surrogate Recovery

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits.

b. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

c. Laboratory Control Samples

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

V. Target Compound Identification

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VI. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VII. System Performance

The system performance was acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

IX. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Diesel Range Organics - Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Diesel Range Organics - Laboratory Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Diesel Range Organics - Field Blank Data Qualification Summary - SDG
F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A8
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET

Level III/IV

Date: 6/15/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC Diesel Range Organics (EPA SW846 Method 8015B)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
IIa.	Initial calibration	A	
IIb.	Calibration verification/ICV	A	ICV = 1570
III.	Blanks	A	
IVa.	Surrogate recovery	A	
IVb.	Matrix spike/Matrix spike duplicates	A	
IVc.	Laboratory control samples	A	LCS
V.	Target compound identification	A	Not reviewed for Level III validation.
VI.	Compound Quantitation and CRQLs	A	Not reviewed for Level III validation.
VII.	System Performance	A	Not reviewed for Level III validation.
VIII.	Overall assessment of data	A	
IX.	Field duplicates	N	
X.	Field blanks	ND	R=1 -

Note: A = Acceptable ND = No compounds detected D = Duplicate
 N = Not provided/applicable R = Rinsate TB = Trip blank
 SW = See worksheet FB = Field blank EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	8169241NB	21		31	
2	TSB-CJ-09-0	S	12	8170312MB	22		32	
3	TSB-CJ-09-10**	W	13		23		33	
4	RINSATE-2MS	W	14		24		34	
5	RINSATE-2MSD	W	15		25		35	
6	TSB-CJ-09-0MS	S	16		26		36	
7	TSB-CJ-09-0MSD	W	17		27		37	
8			18		28		38	
9			19		29		39	
10			20		30		40	

Notes: _____

LDC #: 19A18
 SDG #: SA-COV

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: GC HPLC

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Cooler temperature criteria was met.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
II. Initial calibration				
Did the laboratory perform a 5 point calibration prior to sample analysis?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a linear fit used for evaluation? If yes, were all percent relative standard deviations (%RSD) < 20%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a curve fit used for evaluation? If Yes, what was the acceptance criteria used?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Did the initial calibration meet the curve fit acceptance criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the RT windows properly established?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
III. Continuing calibration				
What type of continuing calibration calculation was performed? <input checked="" type="checkbox"/> %D or %R	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a continuing calibration analyzed daily?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all percent differences (%D) < 15%.0 or percent recoveries 85-115%?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were all the retention times within the acceptance windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IV. Blanks				
Was a method blank associated with every sample in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a method blank analyzed for each matrix and concentration?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
V. Surrogate spikes				
Were all surrogate %R within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
If the percent recovery (%R) of one or more surrogates was outside QC limits, was a reanalysis performed to confirm %R?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
VI. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was a MS/MSD analyzed every 20 samples of each matrix?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
VII. Laboratory control samples				
Was an LCS analyzed for this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

LDC #: 19191A8
 SDG #: See down

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	/			
IX: Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?		/	/	
Were the performance evaluation (PE) samples within the acceptance limits?			/	
X: Target compound identification				
Were the retention times of reported detects within the RT windows?	/			
XI: Compound quantitation/CRQLs				
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	/			
XII: System performance				
System performance was found to be acceptable.	/			
XIII: Overall assessment of data				
Overall assessment of data was found to be acceptable.	/			
XIV: Field duplicates				
Were field duplicate pairs identified in this SDG?		/		
Were target compounds detected in the field duplicates?			/	
XV: Field blanks				
Were field blanks identified in this SDG?	/	/		
Were target compounds detected in the field blanks?			/	

LDC #: 1991A8
 SDG #: Beckon

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 6 of 8
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC HPLC _____

The calibration Factor (CF), average CF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

- CF = A/C
- average CF = sum of the CF/number of standards
- %RSD = $100 * (S/X)$
- A = Area of compound,
- C = Concentration of compound,
- S = Standard deviation of the CF
- X = Mean of the CFs

#	Standard ID	Calibration Date	Compound	Reported		Recalculated		Reported		Recalculated	
				CF (100 std)	CF (102 std)	Average CF (initial)	Average CF (initial)	%RSD	%RSD		
1	10AC	5/16/08	DR 0	15394	15394	16023	16023	3.456	3.456	3.456	3.456
2											
3											
4											

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 1919188
 SDG #: See COM

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC HPLC _____

The percent difference (%D) of the initial calibration average Calibration Factors (CF) and the continuing calibration CF were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \cdot (\text{ave. CF} - \text{CF}) / \text{ave. CF}$ Where: ave. CF = initial calibration average CF
 CF = A/C CF = continuing calibration CF
 A = Area of compound
 C = Concentration of compound

#	Standard ID	Calibration Date	Compound	Average CF (Ical)/ CCV Conc.	Reported		Recalculated	
					CF/Conc. CCV	%D	CF/Conc. CCV	%D
1	<u>20A2575</u>	<u>6/19/08</u>	<u>DRD</u>	<u>1000</u>	<u>979.873</u>	<u>2.0</u>	<u>979.80</u>	<u>2.0</u>
2	<u>20A2586</u>	<u>6/19/08</u>	<u>DRD</u>	<u>1000</u>	<u>1005.376</u>	<u>0.5</u>	<u>1005.32</u>	<u>0.5</u>
3								
4								

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 199AB3
 SDG #: 200000

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

Page: 6 of 7
 Reviewer: 9
 2nd reviewer: 2

METHOD: ✓ GC HPLC

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: SF/SS * 100
 Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 3

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	
TPH	NS	0.50	21.8080	87	87	0

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery		Percent Difference
				Reported	Recalculated	

METHOD: GC HPLC

The percent recoveries (%R) and relative percent differences (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

%Recovery = $100 * (SSC - SC) / SA$ Where SSC = Spiked sample concentration SC = Sample concentration
 SA = Spike added
 MS = Matrix spike

RPD = $\frac{((SSCMS - SSCMSD) * 2) / ((SSCMS + SSCMSD)) * 100}{100}$ MSD = Matrix spike duplicate

MS/MSD samples: 6/7

Compound	Spike Added (MS/MSD)		Sample Conc. (MS/MSD)	Spike Sample Concentration (MS/MSD)		Matrix spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		MS/MSD RPD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)											
Diesel (8015)	85.8	86.6	ND	76.1	71.0	89	89	92	82	69	69
Benzene (8021B)											
Methane (RSK-175)											
2,4-D (8151)											
Dinoseb (8151)											
Naphthalene (8310)											
Anthracene (8310)											
HMX (8330)											
2,4,6-Trinitrotoluene (8330)											

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

METHOD: GC HPLC

The percent recoveries (%R) and Relative Percent difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC-SC)/SA$ Where: SSC = Spiked sample concentration SC = Concentration
SA = Spike added
RPD = $100 * |SSCLCS - SSCLCSD| / (SSCLCS + SSCLCSD)$ LCS = Laboratory control sample percent recovery LCSD = Laboratory control sample duplicate percent recovery

LCS/LCSD samples: 8170312

Compound	Spike Added (1158)		Spiked Sample Concentration (1158)		LCS		LCSD		Percent Recovery		LCS/LCSD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)												
Diesel (8015)	83.3	NA	73.6	NA	88	88						
Benzene (8021B)												
Methane (RSK-175)												
2,4-D (8151)												
Dinoseb (8151)												
Naphthalene (8310)												
Anthracene (8310)												
HMX (8330)												
2,4,6-Trinitrotoluene (8330)												

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Sample Calculation Verification

LDC #: 1977AS
 SDG #: 2e.com

METHOD: GC HPLC

Y/N N/A Were all reported results recalculated and verified for all level IV samples?
 Y/N N/A Were all recalculated results for detected target compounds agree within 10% of the reported results?

Concentration = $\frac{A(E_v)(D_f)}{(RF)(V_s \text{ or } W_s)(\%S/100)}$
 Example: Sample ID: 3 Compound Name: ND

Concentration = _____

- A= Area or height of the compound to be measured
- Fv= Final Volume of extract
- Df= Dilution Factor
- RF= Average response factor of the compound in the initial calibration
- Vs= Initial volume of the sample
- Ws= Initial weight of the sample
- %S= Percent Solid

#	Sample ID	Compound	Reported Concentrations ()	Recalculated Results Concentrations ()	Qualifications

Comments: _____

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 6, 2008
Matrix: Soil/Water
Parameters: Polynuclear Aromatic Hydrocarbons
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
RINSATE-2MS
RINSATE-2MSD
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and 3 water samples listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8310 for Polynuclear Aromatic Hydrocarbons.

This review follows a modified outline of the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review (October 1999) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section III.

Field duplicates are summarized in Section IX.

Samples indicated by a double asterisk on the front cover underwent an EPA Level IV review. An EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. Calibration

a. Initial Calibration

Initial calibration of compounds was performed as required by the method.

The percent relative standard deviations (%RSD) were less than or equal to 20.0% for all compounds.

Retention time windows were evaluated and considered technically acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

b. Calibration Verification

Calibration verification was performed at required frequencies.

The percent differences (%D) of calibration factors in continuing standard mixtures were within the 15.0% QC limits.

The percent differences (%D) of the second source calibration standard were less than or equal to 25.0% for all compounds with the following exceptions:

Date	Column ID	Compound	%D	Associated Samples	Flag	A or P
6/4/08 (QICV768)	Not specified	Benzo(k)fluoranthene	16.6	All samples in SDG F8F130140	J+ (all detects)	A

Retention time windows were evaluated and considered technically acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples on which a Level III review was performed.

III. Blanks

Method blanks were reviewed for each matrix as applicable. No polynuclear aromatic hydrocarbon contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No polynuclear aromatic hydrocarbon contaminants were found in this blank.

IV. Accuracy and Precision Data

a. Surrogate Recovery

Surrogates were added to all samples and blanks as required by the method. All surrogate recoveries (%R) were within QC limits.

b. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Percent recoveries (%R) and relative percent differences (RPD) were within QC limits.

c. Laboratory Control Samples

Laboratory control samples were reviewed for each matrix as applicable. Percent recoveries (%R) were within QC limits.

V. Target Compound Identification

All target compound identifications were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VI. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VII. System Performance

The system performance was acceptable for samples on which an EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by Level III criteria.

VIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

IX. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
 Polynuclear Aromatic Hydrocarbons - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	RINSATE-2 TSB-CJ-09-0 TSB-CJ-09-10**	Benzo(k)fluoranthene	J+ (all detects)	A	Continuing calibration (ICV %D)

**BRC Tronox Parcel C
 Polynuclear Aromatic Hydrocarbons - Laboratory Blank Data Qualification Summary
 - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
 Polynuclear Aromatic Hydrocarbons - Field Blank Data Qualification Summary -
 SDG F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A9
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 6/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC Polynuclear Aromatic Hydrocarbons (EPA SW 846 Method 8310)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
IIa.	Initial calibration	A	
IIb.	Calibration verification/ICV	W	ICV = 1570
III.	Blanks	A	
IVa.	Surrogate recovery	A	
IVb.	Matrix spike/Matrix spike duplicates	A	
IVc.	Laboratory control samples	A	105
V.	Target compound identification	A	Not reviewed for Level III validation.
VI.	Compound Quantitation and CRQLs	A	Not reviewed for Level III validation.
VII.	System Performance	A	Not reviewed for Level III validation.
VIII.	Overall assessment of data	A	
IX.	Field duplicates	N	
X.	Field blanks	ND	R=1

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	81687/87 MB	21		31	
2	TSB-CJ-09-0	W	12	8170313 MB	22		32	
3	TSB-CJ-09-10**	W	13		23		33	
4	RINSATE-2MS	W	14		24		34	
5	RINSATE-2MSD	W	15		25		35	
6	TSB-CJ-09-0MS	W	16		26		36	
7	TSB-CJ-09-0MSD	W	17		27		37	
8			18		28		38	
9			19		29		39	
10			20		30		40	

Notes: _____

VALIDATION FINDINGS WORKSHEET

METHOD: ___ GC ___ HPLC

8310	8330	8151	8141	8141(Con't)	8021B
A. Acenaphthene	A. HMX	A. 2,4-D	A. Dichlorvos	V. Fensulfothion	V. Benzene
B. Acenaphthylene	B. RDX	B. 2,4-DB	B. Mevinphos	W. Bolstar	CC. Toluene
C. Anthracene	C. 1,3,5-Trinitrobenzene	C. 2,4,5-T	C. Demeton-O	X. EPN	EE. Ethyl Benzene
D. Benzo(a)anthracene	D. 1,3-Dinitrobenzene	D. 2,4,5-TP	D. Demeton-S	Y. Azinphos-methyl	SSS. O-Xylene
E. Benzo(a)pyrene	E. Tetryl	E. Dinoseb	E. Ethoprop	Z. Coumaphos	RRR. MP-Xylene
F. Benzo(b)fluoranthene	F. Nitrobenzene	F. Dichlorprop	F. Naled	AA. Parathion	GG. Total Xylene
G. Benzo(g,h,i)perylene	G. 2,4,6-Trinitrotoluene	G. Dicamba	G. Sulfotep	BB. Trichloronate	
H. Benzo(k)fluoranthene	H. 4-Amino-2,6-dinitrotoluene	H. Dalapon	H. Phorate	CC. Trichlorinate	
I. Chrysene	I. 2-Amino-4,6-dinitrotoluene	I. MCPP	I. Dimethoate	DD. Trifluralin	
J. Dibenz(a,h)anthracene	J. 2,4-Dinitrotoluene	J. MCPA	J. Diazinon	EE. Def	
K. Fluoranthene	K. 2,6-Dinitrotoluene	K. Pentachlorophenol	K. Disulfoton	FF. Prowl	
L. Fluorene	L. 2-Nitrotoluene	L., 2,4,5-TP (silvex)	L. Parathion-methyl	GG. Ethion	
M. Indeno(1,2,3-cd)pyrene	M. 3-Nitrotoluene	M. Silvex	M. Ronnel	HH. Tetrachlorvinphos	
N. Naphthalene	N. 4-Nitrotoluene		N. Malathion	II. Sulprofos	
O. Phenanthrene	O.		O. Chlorpyrifos		
P. Pyrene	P.		P. Fenthion		
Q.	Q		Q. Parathion-ethyl		
R.			R. Trichloronate		
S.			S. Merphos		
			T. Stirofos		
			U. Tokuthion		

Notes:

LDC #: 19191A9
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: GC HPLC

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	<input checked="" type="checkbox"/>			
Cooler temperature criteria was met.	<input checked="" type="checkbox"/>			
II. Initial calibration				
Did the laboratory perform a 5 point calibration prior to sample analysis?	<input checked="" type="checkbox"/>			
Was a linear fit used for evaluation? If yes, were all percent relative standard deviations (%RSD) < 20%?	<input checked="" type="checkbox"/>			
Was a curve fit used for evaluation? If Yes, what was the acceptance criteria used?		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Did the initial calibration meet the curve fit acceptance criteria?	<input checked="" type="checkbox"/>			
Were the RT windows properly established?	<input checked="" type="checkbox"/>			
III. Continuing calibration				
What type of continuing calibration calculation was performed? <u>✓</u> %D or %R	<input checked="" type="checkbox"/>			
Was a continuing calibration analyzed daily?	<input checked="" type="checkbox"/>			
Were all percent differences (%D) < 15%.0 or percent recoveries 85-115%?	<input checked="" type="checkbox"/>			
Were all the retention times within the acceptance windows?	<input checked="" type="checkbox"/>			
IV. Blanks				
Was a method blank associated with every sample in this SDG?	<input checked="" type="checkbox"/>			
Was a method blank analyzed for each matrix and concentration?	<input checked="" type="checkbox"/>			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet.		<input checked="" type="checkbox"/>		
V. Surrogate spikes				
Were all surrogate %R within the QC limits?	<input checked="" type="checkbox"/>			
If the percent recovery (%R) of one or more surrogates was outside QC limits, was a reanalysis performed to confirm %R?			<input checked="" type="checkbox"/>	
If any %R was less than 10 percent, was a reanalysis performed to confirm %R?			<input checked="" type="checkbox"/>	
VI. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	<input checked="" type="checkbox"/>			
Was a MS/MSD analyzed every 20 samples of each matrix?	<input checked="" type="checkbox"/>			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?	<input checked="" type="checkbox"/>			
VII. Laboratory control samples				
Was an LCS analyzed for this SDG?	<input checked="" type="checkbox"/>			
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>			

LDC #: 19191A9
 SDG #: See COMV

VALIDATION FINDINGS CHECKLIST

Page: 2 of 2
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
IX. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
X. Target compound identification				
Were the retention times of reported detects within the RT windows?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Compound quantitation/CRQLs				
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIV. Field duplicates				
Were field duplicate pairs identified in this SDG?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field duplicates?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
XV. Field blanks				
Were field blanks identified in this SDG?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were target compounds detected in the field blanks?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

LDC #: 199189
 SDG #: 2020W

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC HPLC

The calibration Factor (CF), average CF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

- CF = A/C
- average CF = sum of the CF/number of standards
- %RSD = $100 * (S/X)$
- A = Area of compound,
- C = Concentration of compound,
- S = Standard deviation of the CF
- X = Mean of the CFs

#	Standard ID	Calibration Date	Compound	Reported		Recalculated		Reported		Recalculated	
				CF (/ std)	CF (/ std)	Average CF (Initial)	Average CF (Initial)	%RSD	%RSD	%RSD	%RSD
1	<u>10A/C</u>	<u>6/4/08</u>	<u>C</u>	<u>807269</u>	<u>807269</u>	<u>806710</u>	<u>806710</u>	<u>1.821</u>	<u>1.821</u>	<u>17.820</u>	<u>17.820</u>
			<u>#</u>	<u>67485</u>	<u>67485</u>	<u>6260.8</u>	<u>6260.8</u>				
2											
3											
4											

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 19191A9
 SDG #: See down

VALIDATION FINDINGS WORKSHEET
Continuing Calibration Results Verification

Page: 6 of 9
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: GC _____ HPLC

The percent difference (%D) of the initial calibration average Calibration Factors (CF) and the continuing calibration CF were recalculated for the compounds identified below using the following calculation:

% Difference = $100 \cdot (\text{ave. CF} - \text{CF}) / \text{ave. CF}$ Where: ave. CF = Initial calibration average CF
 CF = A/C CF = continuing calibration CF
 A = Area of compound
 C = Concentration of compound

#	Standard ID	Calibration Date	Compound	Average CF (cal)/ CCV Conc.	Reported		Recalculated	
					CF/Conc. CCV	%D	CF/Conc. CCV	%D
1	<u>8CA2B1</u>	<u>6/19/08</u>	<u>C</u>	<u>0.50</u>	<u>0.4790</u>	<u>4.2</u>	<u>0.4790</u>	<u>4.2</u>
			<u>P</u>	<u>✓</u>	<u>0.4289</u>	<u>14.2</u>	<u>0.4289</u>	<u>14.2</u>
2								
3								
4								

Comments: Refer to Continuing Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

LDC #: 191A9
 SDG #: SecCom

VALIDATION FINDINGS WORKSHEET
Surrogate Results Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd reviewer: [Signature]

METHOD: GC HPLC

The percent recoveries (%R) of surrogates were recalculated for the compounds identified below using the following calculation:

% Recovery: $SF/SS * 100$
 Where: SF = Surrogate Found
 SS = Surrogate Spiked

Sample ID: 3

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference
TPH	NS	25	21.7512	87	87	0

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference

Sample ID: _____

Surrogate	Column/Detector	Surrogate Spiked	Surrogate Found	Percent Recovery Reported	Percent Recovery Recalculated	Percent Difference

METHOD: GC HPLC

The percent recoveries (%R) and relative percent differences (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

$$\% \text{Recovery} = 100 * (\text{SSC} - \text{SC}) / \text{SA}$$

Where

SSC = Spiked sample concentration
SA = Spike added
MS = Matrix spike

SC = Sample concentration
MSD = Matrix spike duplicate

$$\text{RPD} = \frac{((\text{SSCMS} - \text{SSCMSD}) * 2) / (\text{SSCMS} + \text{SSCMSD}) * 100}{}$$

MS/MSD samples: 6/7

Compound	Spike Added		Sample Conc. (MSD)	Spike Sample Concentration		Matrix spike		Matrix Spike Duplicate		MS/MSD	
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)											
Diesel (8015)											
Benzene (8021B)											
Methane (RSK-175)											
2,4-D (8151)											
Dinoseb (8151)											
Naphthalene (8310) P	68.2	68.2	ND	55.1	56.0	81	81	82	82	1.7	1.6
Anthracene (8310)	↓	↓	↓	49.1	50.9	72	72	75	75	3.6	3.6
HMX (8330)											
2,4,6-Trinitrotoluene (8330)											

Comments: Refer to Matrix Spike/Matrix Spike Duplicates findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

METHOD: GC HPLC

The percent recoveries (%R) and Relative Percent difference (RPD) of the laboratory control sample and laboratory control sample duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSC-SC) / SA$

Where: SSC = Spiked sample concentration
 SA = Spike added

RPD = $100 * |SSCLCS - SSCLCSD| / (SSCLCS + SSCLCSD)$

LCS = Laboratory control sample percent recovery
 LCSD = Laboratory control sample duplicate percent recovery

LCS/LCSD samples: 8170313

Compound	Spike Added		Spiked Sample Concentration		LCS		LCSD		Percent Recovery		RPD	
	LCS	LCSD	LCS	LCSD	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.	Reported	Recalc.
Gasoline (8015)												
Diesel (8015)												
Benzene (8021B)												
Methane (RSK-175)												
2,4-D (8151)												
Dinoseb (8151)												
Naphthalene (8310) <u>P</u>	<u>66.7</u>	<u>NA</u>	<u>56.6</u>	<u>NA</u>	<u>85</u>	<u>85</u>						
Anthracene (8310)	<u>↓</u>	<u>↓</u>	<u>53.9</u>	<u>↓</u>	<u>81</u>	<u>81</u>						
HMX (8330)												
2,4,6-Trinitrotoluene (8330)												

Comments: Refer to Laboratory Control Sample/Laboratory Control Sample Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

**Laboratory Data Consultants, Inc.
Data Validation Report**

Project/Site Name: BRC Tronox Parcel C
Collection Date: June 12, 2008
LDC Report Date: August 7, 2008
Matrix: Soil/Water
Parameters: Dioxins/Dibenzofurans
Validation Level: EPA Level III & IV
Laboratory: TestAmerica, Inc.

Sample Delivery Group (SDG): F8F130140

Sample Identification

RINSATE-2
TSB-CJ-09-0
TSB-CJ-09-10**
TSB-CJ-09-0MS
TSB-CJ-09-0MSD

**Indicates sample underwent EPA Level IV review

Introduction

This data review covers 4 soil samples and one water sample listed on the cover sheet including dilutions and reanalysis as applicable. The analyses were per EPA SW 846 Method 8290 for Polychlorinated Dioxins/Dibenzofurans.

This review follows USEPA Contract Laboratory Program National Functional Guidelines for Polychlorinated Dioxins/Dibenzofurans Data Review (September 2005) as there are no current guidelines for the method stated above.

A qualification summary table is provided at the end of this report if data has been qualified. Flags are classified as P (protocol) or A (advisory) to indicate whether the flag is due to a laboratory deviation from a specified protocol or is of technical advisory nature.

Blank results are summarized in Section V.

Field duplicates are summarized in Section XIV.

Samples indicated by a double asterisk on the front cover underwent EPA Level IV review. EPA Level III review was performed on all of the other samples. Raw data were not evaluated for the samples reviewed by EPA Level III criteria since this review is based on QC data.

The following are definitions of the data qualifiers:

- J+ Data are qualified as estimated, with a high bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J- Data are qualified as estimated, with a low bias likely to occur. False positives or false negatives are unlikely to have been reported.
- J Data are qualified as estimated; it is not possible to assess the direction of the potential bias. False positives or false negatives are unlikely to have been reported.
- U Indicates the compound or analyte was analyzed for but not detected at or above the stated limit.
- R Data are qualified as rejected. There is a significant potential for the reporting of false negatives or false positives.
- UU Indicates the compound or analyte was analyzed for but not detected. The sample detection limit is an estimated value.
- A Indicates the finding is based upon technical validation criteria.
- P Indicates the finding is related to a protocol/contractual deviation.
- None Indicates the data was not significantly impacted by the finding, therefore qualification was not required.

I. Technical Holding Times

All technical holding time requirements were met.

The chain-of-custodies were reviewed for documentation of cooler temperatures. All cooler temperatures met validation criteria.

II. HRGC/HRMS Instrument Performance Check

Instrument performance was checked at the required daily frequency.

Retention time windows were established for all homologues. The chromatographic resolution between 2,3,7,8-TCDD and peaks representing any other unlabeled TCDD isomer was less than or equal to 25% .

The exact mass of 380.9760 of PFK was verified. The static resolving power was at least 10,000 (10% valley definition) for samples on which EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by EPA Level III criteria.

III. Initial Calibration

A five point initial calibration was performed as required by the method.

Percent relative standard deviations (%RSD) were less than or equal to 20.0% for unlabeled compounds and less than or equal to 30.0% for labeled compounds.

The ion abundance ratios for all PCDDs and PCDFs were within validation criteria.

The minimum S/N ratio for each target compound was greater than or equal to 2.5 and and greater than or equal to 10 for each recovery and internal standard compound for samples on which EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by EPA Level III criteria.

IV. Routine Calibration (Continuing)

Routine calibration was performed at the required frequencies.

All of the routine calibration percent differences (%D) between the initial calibration RRF and the routine calibration RRF were less than or equal to 20.0% for unlabeled compounds and less than or equal to 30.0% for labeled compounds with the following exceptions:

Date	Compound	%D	Associated Samples	Affected Compound	Flag	A or P
7/3/08 (02JL08B1D2_20)	¹³ C-2,3,7,8-TCDF	57.3	TSB-CJ-09-0 TSB-CJ-09-0MS TSB-CJ-09-0MSD	2,3,7,8-TCDF	J+ (all detects)	P

Date	Compound	%D	Associated Samples	Affected Compound	Flag	A or P
7/3/08 (02JL08B1D2_32)	¹³ C-2,3,7,8-TCDF	71.8	TSB-CJ-09-0 TSB-CJ-09-0MS TSB-CJ-09-0MSD	2,3,7,8-TCDF	J+ (all detects)	P
6/26/08	¹³ C-OCDD	34.6	8175566MB	OCDD	J+ (all detects)	P

The ion abundance ratios for all PCDDs and PCDFs were within validation criteria.

V. Blanks

Method blanks were reviewed for each matrix as applicable. No polychlorinated dioxin/dibenzofuran contaminants were found in the method blanks.

Sample RINSATE-2 was identified as a rinsate. No polychlorinated dioxin/dibenzofuran contaminants were found in this blank.

VI. Matrix Spike/Matrix Spike Duplicates

Matrix spike (MS) and matrix spike duplicate (MSD) samples were reviewed for each matrix as applicable. Although the MS/MSD percent recoveries (%R) and relative percent differences (RPD) were not within QC limits for some compounds, the LCS percent recovery (%R) was within QC limits and no data were qualified.

VII. Laboratory Control Samples (LCS)

Laboratory control samples were reviewed for each matrix as applicable. The percent recoveries (%R) were within the QC limits with the following exceptions:

LCS ID	Compound	%R (Limits)	Associated Samples	Flag	A or P
8172352LCS	1,2,3,7,8,9-HxCDD	129 (74-126)	All water samples in SDG F8F130140	J+ (all detects)	P

VIII. Regional Quality Assurance and Quality Control

Not applicable.

IX. Internal Standards

All internal standard recoveries were within QC limits with the following exceptions:

Sample	Internal Standards	%R (Limits)	Compound	Flag	A or P
RINSATE-2	¹³ C-1,2,3,4,7,8-HxCDF ¹³ C-1,2,3,6,7,8-HxCDD ¹³ C-1,2,3,4,6,7,8-HpCDF	26 (40-135) 37 (40-135) 33 (40-135)	1,2,3,4,7,8-HxCDD 1,2,3,6,7,8-HxCDD 1,2,3,7,8,9-HxCDD 1,2,3,4,7,8-HxCDF 1,2,3,6,7,8-HxCDF 2,3,4,6,7,8-HxCDF 1,2,3,7,8,9-HxCDF 1,2,3,4,6,7,8-HpCDF 1,2,3,4,7,8,9-HpCDF	J (all detects) UJ (all non-detects)	P
TSB-CJ-09-10**	¹³ C-1,2,3,4,7,8-HxCDF ¹³ C-1,2,3,6,7,8-HxCDD ¹³ C-1,2,3,4,6,7,8-HpCDF ¹³ C-1,2,3,4,6,7,8-HpCDD ¹³ C-OCDD	25 (40-135) 32 (40-135) 14 (40-135) 16 (40-135) 13 (40-135)	1,2,3,4,7,8-HxCDD 1,2,3,6,7,8-HxCDD 1,2,3,7,8,9-HxCDD 1,2,3,4,6,7,8-HpCDD OCDD 1,2,3,4,7,8-HxCDF 1,2,3,6,7,8-HxCDF 2,3,4,6,7,8-HxCDF 1,2,3,7,8,9-HxCDF 1,2,3,4,6,7,8-HpCDF 1,2,3,4,7,8,9-HpCDF OCDF	J (all detects) UJ (all non-detects)	P

X. Target Compound Identifications

All target compound identifications were within validation criteria for samples on which EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by EPA Level III criteria.

XI. Compound Quantitation and CRQLs

All compound quantitation and CRQLs were within validation criteria with the following exceptions:

Sample	Compound	Finding	Criteria	Flag	A or P
TSB-CJ-09-0	2,3,7,8-TCDF OCDF	Sample result exceeded calibration range.	Reported result should be within calibration range.	J (all detects) J (all detects)	P

Raw data were not evaluated for the samples reviewed by EPA Level III criteria.

XII. System Performance

The system performance was acceptable for samples on which EPA Level IV review was performed. Raw data were not evaluated for the samples reviewed by EPA Level III criteria.

XIII. Overall Assessment of Data

Data flags are summarized at the end of this report if data has been qualified.

XIV. Field Duplicates

No field duplicates were identified in this SDG.

**BRC Tronox Parcel C
Dioxins/Dibenzofurans - Data Qualification Summary - SDG F8F130140**

SDG	Sample	Compound	Flag	A or P	Reason
F8F130140	TSB-CJ-09-0	2,3,7,8-TCDF	J+ (all detects)	P	Routine calibration (%D)
F8F130140	RINSATE-2	1,2,3,7,8,9-HxCDD	J+ (all detects)	P	Laboratory control samples (%R)
F8F130140	RINSATE-2	1,2,3,4,7,8-HxCDD 1,2,3,6,7,8-HxCDD 1,2,3,7,8,9-HxCDD 1,2,3,4,7,8-HxCDF 1,2,3,6,7,8-HxCDF 2,3,4,6,7,8-HxCDF 1,2,3,7,8,9-HxCDF 1,2,3,4,6,7,8-HpCDF 1,2,3,4,7,8,9-HpCDF	J (all detects) UJ (all non-detects)	P	Internal standards (%R)
F8F130140	TSB-CJ-09-10**	1,2,3,4,7,8-HxCDD 1,2,3,6,7,8-HxCDD 1,2,3,7,8,9-HxCDD 1,2,3,4,6,7,8-HpCDD OCDD 1,2,3,4,7,8-HxCDF 1,2,3,6,7,8-HxCDF 2,3,4,6,7,8-HxCDF 1,2,3,7,8,9-HxCDF 1,2,3,4,6,7,8-HpCDF 1,2,3,4,7,8,9-HpCDF OCDF	J (all detects) UJ (all non-detects)	P	Internal standards (%R)
F8F130140	TSB-CJ-09-0	2,3,7,8-TCDF OCDF	J (all detects) J (all detects)	P	Compound quantitation and CRQLs

**BRC Tronox Parcel C
Dioxins/Dibenzofurans - Laboratory Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

**BRC Tronox Parcel C
Dioxins/Dibenzofurans - Field Blank Data Qualification Summary - SDG F8F130140**

No Sample Data Qualified in this SDG

LDC #: 19191A21
 SDG #: F8F130140
 Laboratory: Test America

VALIDATION COMPLETENESS WORKSHEET
 Level III/IV

Date: 8/5/08
 Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

The samples listed below were reviewed for each of the following validation areas. Validation findings are noted in attached validation findings worksheets.

	Validation Area		Comments
I.	Technical holding times	A	Sampling dates: 6/12/08
II.	GC/MS Instrument performance check	A	
III.	Initial calibration	A	
IV.	Routine calibration/ICV	W	
V.	Blanks	A	
VI.	Matrix spike/Matrix spike duplicates	W	
VII.	Laboratory control samples	W	LCS
VIII.	Regional quality assurance and quality control	N	
IX.	Internal standards	W	
X.	Target compound identifications	A	Not reviewed for Level III validation.
XI.	Compound quantitation and CRQLs	W	Not reviewed for Level III validation.
XII.	System performance	A	Not reviewed for Level III validation.
XIII.	Overall assessment of data	A	
XIV.	Field duplicates	N	
XV.	Field blanks	ND	R=1

Note: A = Acceptable
 N = Not provided/applicable
 SW = See worksheet
 ND = No compounds detected
 R = Rinsate
 FB = Field blank
 D = Duplicate
 TB = Trip blank
 EB = Equipment blank

Validated Samples: ** Indicates sample underwent Level IV validation

1	RINSATE-2	W	11	8172252MB	21	31
2	TSB-CJ-09-0	S	12	8175566MB	22	32
3	TSB-CJ-09-10**		13		23	33
4	TSB-CJ-09-0MS		14		24	34
5	TSB-CJ-09-0MSD		15		25	35
6			16		26	36
7			17		27	37
8			18		28	38
9			19		29	39
10			20		30	40

Notes: _____

LDC #: 19191A21
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 1 of 3
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Method: Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

Validation Area	Yes	No	NA	Findings/Comments
I. Technical holding times				
All technical holding times were met.	/			
Cooler temperature criteria was met.	/			
II. GC/MS Instrument performance check				
Was PFK exact mass 380.9760 verified?	/			
Were the retention time windows established for all homologues?	/			
Was the chromatographic resolution between 2,3,7,8-TCDD and peaks representing any other unlabeled TCDD isomers $\leq 25\%$?	/			
Is the static resolving power at least 10,000 (10% valley definition)?	/			
Was the mass resolution adequately check with PFK?	/			
Was the presence of 1,2,8,9-TCDD and 1,3,4,6,8-PeCDF verified?	/			
III. Initial calibration				
Was the initial calibration performed at 5 concentration levels?	/			
Were all percent relative standard deviations (%RSD) $\leq 20\%$ for unlabeled standards and $\leq 30\%$ for labeled standards?	/			
Did all calibration standards meet the Ion Abundance Ratio criteria?	/			
Was the signal to noise ratio for each target compound ≥ 2.5 and for each recovery and internal standard ≥ 10 ?	/			
IV. Continuing calibration				
Was a routine calibration performed at the beginning and end of each 12 hour period?	/			
Were all percent differences (%D) $\leq 20\%$ for unlabeled standards and $\leq 30\%$ for labeled standards?	/			
Did all routine calibration standards meet the Ion Abundance Ratio criteria?	/			
V. Blanks				
Was a method blank associated with every sample in this SDG?	/			
Was a method blank performed for each matrix and concentration?	/			
Was there contamination in the method blanks? If yes, please see the Blanks validation completeness worksheet?		/		
VI. Matrix spike/Matrix spike duplicates				
Were a matrix spike (MS) and matrix spike duplicate (MSD) analyzed for each matrix in this SDG? If no, indicate which matrix does not have an associated MS/MSD. Soil / Water.	/			
Were the MS/MSD percent recoveries (%R) and the relative percent differences (RPD) within the QC limits?		/		
VII. Laboratory control samples				
Was an LCS analyzed for this SDG?	/			

LDC #: 19A1A21
 SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 2 of 3
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Was an LCS analyzed per extraction batch?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were the LCS percent recoveries (%R) and relative percent difference (RPD) within the QC limits?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
VIII. Regional Quality Assurance and Quality Control				
Were performance evaluation (PE) samples performed?	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Were the performance evaluation (PE) samples within the acceptance limits?	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
IX. Internal standards				
Were internal standard recoveries within the 40-135% criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was the minimum S/N ratio of all internal standard peaks ≥ 10 ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
X. Target compound identification				
For 2,3,7,8 substituted congeners with associated labeled standards, were the retention times of the two quantitation peaks within -1 to 3 sec. of the RT of the labeled standard?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
For 2,3,7,8 substituted congeners without associated labeled standards, were the relative retention times of the two quantitation peaks within 0.005 time units of the RRT measured in the routine calibration?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
For non-2,3,7,8 substituted congeners, were the retention times of the two quantitation peaks within RT established in the performance check solution?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Did compound spectra contain all characteristic ions listed in the table attached?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was the Ion Abundance Ratio for the two quantitation ions within criteria?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Was the signal to noise ratio for each target compound and labeled standard ≥ 2.5 ?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Does the maximum intensity of each specified characteristic ion coincide within ± 2 seconds (includes labeled standards)?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
For PCDF identification, was any signal ($S/N \geq 2.5$, at \pm seconds RT) detected in the corresponding PCDPE channel?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Was an acceptable lock mass recorded and monitored?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XI. Compound quantitation/CRQLs				
Were the correct internal standard (IS), quantitation ion and relative response factor (RRF) used to quantitate the compound?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Were compound quantitation and CRQLs adjusted to reflect all sample dilutions and dry weight factors applicable to level IV validation?	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XII. System performance				
System performance was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIII. Overall assessment of data				
Overall assessment of data was found to be acceptable.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
XIV. Field duplicates				
Field duplicate pairs were identified in this SDG.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

LDC #: 19191A21
SDG #: See cover

VALIDATION FINDINGS CHECKLIST

Page: 3 of 3
Reviewer: [Signature]
2nd Reviewer: [Signature]

Validation Area	Yes	No	NA	Findings/Comments
Target compounds were detected in the field duplicates.			/	
XV. Field blanks				
Field blanks were identified in this SDG.	/			
Target compounds were detected in the field blanks.		/		

VALIDATION FINDINGS WORKSHEET

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

A. 2,3,7,8-TCDD	F. 1,2,3,4,6,7,8-HpCDD	K. 1,2,3,4,7,8-HxCDF	P. 1,2,3,4,7,8,9-HpCDF	U. Total HpCDD
B. 1,2,3,7,8-PeCDD	G. OCDD	L. 1,2,3,6,7,8-HxCDF	Q. OCDF	V. Total TCDF
C. 1,2,3,4,7,8-HxCDD	H. 2,3,7,8-TCDF	M. 2,3,4,6,7,8-HxCDF	R. Total TCDD	W. Total PeCDF
D. 1,2,3,6,7,8-HxCDD	I. 1,2,3,7,8-PeCDF	N. 1,2,3,7,8,9-HxCDF	S. Total PeCDD	X. Total HxCDF
E. 1,2,3,7,8,9-HxCDD	J. 2,3,4,7,8-PeCDF	O. 1,2,3,4,6,7,8-HpCDF	T. Total HxCDD	Y. Total HpCDF

Notes:

VALIDATION FINDINGS WORKSHEET
Internal Standards

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

Please see qualifications below for all questions answered "N". Not applicable questions are identified as "N/A".

X N/A Are all internal standard recoveries were within the 40-135% criteria?

Y N/A Was the S/N ratio all internal standard peaks ≥ 10 ?

#	Date	Lab ID/Reference	Internal Standard	% Recovery (Limit: 40-135%)	Qualifications
		1	E	26 (40-135)	Y/N/P (G-E, K-P)
			F	37	↓
			G	33	
		3	E	25	Y/N/P (G-F, K-Q)
			F	32	↓
			G	14	
			H	16	↓
			I	13	
		4 (NS)	D	36 (40-135)	No Qual
			F	36	
			H	32	↓
			I	24	
			C	39	↓
			G	33	↓

Internal Standards	Check Standard Used	Recovery Standards	Check Standard Used
¹³ C-2,3,7,8-TCDF			
¹³ C-2,3,7,8-TCDD		K. ¹³ C-1,2,3,4-TCDD	
¹³ C-1,2,3,7,8-PeCDF		L. ¹³ C-1,2,3,7,8,9-HxCDD	
¹³ C-1,2,3,7,8-PeCDD		M.	
¹³ C-1,2,3,6,7,8-HxCDF		N.	
¹³ C-1,2,3,6,7,8-HxCDD		O.	
¹³ C-1,2,3,4,6,7,8-HpCDF		P.	
¹³ C-1,2,3,4,6,7,8-HpCDD		Q.	
¹³ C-OCDD		R.	
		T.	

LDC #: 19191A2
 SDG #: See cover

VALIDATION FINDINGS WORKSHEET
Initial Calibration Calculation Verification

Page: 1 of 1
 Reviewer: [Signature]
 2nd Reviewer: [Signature]

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

The Relative Response Factor (RRF), average RRF, and percent relative standard deviation (%RSD) were recalculated for the compounds identified below using the following calculations:

$RRF = (A_x)(C_w)/(A_w)(C_x)$
 average RRF = sum of the RRFs/number of standards
 $\%RSD = 100 * (S/X)$
 A_x = Area of compound,
 C_x = Concentration of compound,
 S = Standard deviation of the RRFs,
 A_w = Area of associated internal standard
 C_w = Concentration of internal standard
 X = Mean of the RRFs

#	Standard ID	Calibration Date	Compound (Reference Internal Standard)	Reported		Recalculated		Reported		Recalculated	
				Average RRF (initial)	(%RSD)	Average RRF (initial)	(%RSD)	RRF (CS3 std)	(%RSD)	RRF (CS3 std)	(%RSD)
1	18A2	6/17/08	2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)	0.798	12.5	0.798	12.5	0.82	12.5	0.82	12.70
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)	0.913	10.3	0.913	10.3	0.93	10.3	0.93	10.3
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)	0.821	13.9	0.821	13.9	0.87	13.9	0.87	14.1
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)	0.844	12.7	0.844	12.7	0.88	12.7	0.88	12.7
			OCDF (¹³ C-OCDD)	1.721	16.2	1.721	16.2	1.86	16.2	1.86	16.2
2			2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)								
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)								
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)								
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)								
			OCDF (¹³ C-OCDD)								
3			2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)								
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)								
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)								
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)								
			OCDF (¹³ C-OCDD)								

Comments: Refer to Initial Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Routine Calibration Results Verification

LDC #: 19191 A21
 SDG #: See cover

Page: 1 of 1
 Reviewer: 9
 2nd Reviewer: 8

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

The percent difference (%D) of the initial calibration average Relative Response Factors (RRFs) and the continuing calibration RRFs were recalculated for the compounds identified below using the following calculation:

% Difference = $100 * (\text{ave. RRF} - \text{RRF}) / \text{ave. RRF}$ Where: ave. RRF = initial calibration average RRF
 RRF = $(A_x)(C_s) / (A_s)(C_x)$ RRF = continuing calibration RRF
 A_x = Area of compound, A_s = Area of associated internal standard
 C_x = Concentration of compound, C_s = Concentration of internal standard

#	Standard ID	Calibration Date	Compound (Reference Internal Standard)	Average RRF (Initial)	Reported		Recalculated	
					RRF (CC)	%D	RRF (CC)	%D
1	<u>71628405</u>	<u>6/28/08</u>	2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)	<u>0.798</u>	<u>0.83</u>	<u>4.0</u>	<u>0.83</u>	<u>4.1</u>
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)	<u>0.913</u>	<u>0.81</u>	<u>11.7</u>	<u>0.81</u>	<u>11.7</u>
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)	<u>0.821</u>	<u>0.87</u>	<u>6.5</u>	<u>0.87</u>	<u>6.4</u>
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)	<u>0.844</u>	<u>0.83</u>	<u>1.5</u>	<u>0.83</u>	<u>1.5</u>
			OCDF (¹³ C-OCDD)	<u>1.721</u>	<u>1.58</u>	<u>8.3</u>	<u>1.58</u>	<u>8.3</u>
2			2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)					
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)					
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)					
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)					
			OCDF (¹³ C-OCDD)					
3			2,3,7,8-TCDF (¹³ C-2,3,7,8-TCDF)					
			2,3,7,8-TCDD (¹³ C-2,3,7,8-TCDD)					
			1,2,3,6,7,8-HxCDD (¹³ C-1,2,3,6,7,8-HxCDD)					
			1,2,3,4,6,7,8-HpCDD (¹³ C-1,2,4,6,7,8-HpCDD)					
			OCDF (¹³ C-OCDD)					

Comments: Refer to Routine Calibration findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

VALIDATION FINDINGS WORKSHEET
Matrix Spike/Matrix Spike Duplicates Results Verification

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

The percent recoveries (%R) and Relative Percent Difference (RPD) of the matrix spike and matrix spike duplicate were recalculated for the compounds identified below using the following calculation:

% Recovery = $100 * (SSR - SR) / SA$ Where: SSR = Spiked sample result, SR = Sample result
 SA = Spike added

RPD = $|MSR - MSDR| * 2 / (MSR + MSDR)$ MSR = Matrix spike percent recovery MSDR = Matrix spike duplicate percent recovery

MS/MSD samples: 4/5

Compound	Spike Added (PS/S)		Sample Concentration (PS/S)	Spiked Sample Concentration (PS/S)		Matrix Spike Percent Recovery		Matrix Spike Duplicate Percent Recovery		Reported RPD	Recalculated RPD
	MS	MSD		MS	MSD	Reported	Recalc.	Reported	Recalc.		
2,3,7,8-TCDD	20.9	20.9	78	183	95.9	50.2	50.2	85	86	62	62
1,2,3,7,8-PeCDD	10.4	10.4	330	824	457	47.2	47.5	120	122	57	57
1,2,3,4,7,8-HxCDD	✓	✓	250	697	426	43.1	43.0	172	169	48	48
1,2,3,4,7,8,9-HpCDF	✓	✓	850	1910	1020	10.00	10.192	1650	1635	60	61
OCDF	20.9	20.9	4900	98200	50600	23.00	23.541	618	766	64	64

Comments: Refer to Matrix Spike/Matrix Spike Duplicate findings worksheet for list of qualifications and associated samples when reported results do not agree within 10.0% of the recalculated results.

Ions Monitored for HRGC/HRMS Analysis of PCDDs/PCDFs

Descriptor	Accurate mass ^(b)	Ion ID	Elemental Composition	Analyte	Descriptor	Accurate Mass ^(a)	Ion ID	Elemental Composition	Analyte		
1	303.9016	M	C ₁₂ H ₄ ³⁵ Cl ₄ O	TCDF	4	407.7818	M+2	C ₁₂ H ₃₅ Cl ₃ ³⁷ ClO	HpCDF		
	305.8987	M+2	C ₁₂ H ₄ ³⁵ Cl ₃ ³⁷ Cl ₁₀	TCDF		409.7788	M+4	C ₁₂ H ₃₅ Cl ₂ ³⁷ Cl ₂ O	HpCDF		
	315.9419	M	¹³ C ₁₂ H ₄ ³⁵ Cl ₄ O	TCDF (S)		417.8250	M	¹³ C ₁₂ H ₃₅ Cl ₄ O	HpCDF (S)		
	317.9389	M+2	¹³ C ₁₂ H ₄ ³⁵ Cl ₃ ³⁷ ClO	TCDF (S)		419.8220	M+2	¹³ C ₁₂ H ₃₅ Cl ₂ ³⁷ ClO	HpCDF		
	319.8965	M	C ₁₂ H ₄ ³⁵ Cl ₄ O ₂	TCDD		423.7767	M+2	¹³ C ₁₂ H ₃₅ Cl ₃ ³⁷ ClO ₂	HpCDD		
	321.8936	M+2	C ₁₂ H ₄ ³⁵ Cl ₃ ³⁷ ClO ₂	TCDD		425.7737	M+4	C ₁₂ H ₃₅ Cl ₂ ³⁷ ClO ₂	HpCDD		
	331.9368	M	¹³ C ₁₂ H ₄ ³⁵ Cl ₄ O ₂	TCDD (S)		435.8169	M+2	¹³ C ₁₂ H ₃₅ Cl ₃ ³⁷ ClO ₂	HpCDD (S)		
	333.9338	M+2	¹³ C ₁₂ H ₄ ³⁵ Cl ₃ ³⁷ ClO ₂	TCDD (S)		437.8140	M+4	¹³ C ₁₂ H ₃₅ Cl ₂ ³⁷ ClO ₂	HpCDD (S)		
	375.8364	M+2	C ₁₂ H ₄ ³⁵ Cl ₃ ³⁷ ClO	HxCDFPE		479.7165	M+4	C ₁₂ H ₃₅ Cl ₂ ³⁷ ClO	NCDFPE		
	[354.9792]	LOCK	C ₉ F ₁₃	PFK		[430.9728]	LOCK	C ₉ F ₁₇	PFK		
	2	339.8597	M+2	C ₁₂ H ₃ ³⁵ Cl ₄ ³⁷ ClO		PeCDF	5	441.7428	M+2	C ₁₂ ³⁵ Cl ₇ ³⁷ ClO	OCDF
		341.8567	M+4	C ₁₂ H ₃ ³⁵ Cl ₃ ³⁷ Cl ₂ O		PeCDF		443.7399	M+4	C ₁₂ ³⁵ Cl ₆ ³⁷ Cl ₂ O	OCDF
		351.9000	M+2	¹³ C ₁₂ H ₃ ³⁵ Cl ₄ ³⁷ ClO		PeCDF (S)		457.7377	M+2	¹³ C ₁₂ ³⁵ Cl ₇ ³⁷ ClO ₂	OCDD
353.8970		M+4	¹³ C ₁₂ H ₃ ³⁵ Cl ₃ ³⁷ Cl ₂ O	PeCDF (S)	459.7348	M+4		¹³ C ₁₂ ³⁵ Cl ₆ ³⁷ Cl ₂ O ₂	OCDD		
355.8546		M+2	C ₁₂ H ₃ ³⁵ Cl ₄ ³⁷ ClO ₂	PeCDD	469.7780	M+2		¹³ C ₁₂ ³⁵ Cl ₇ ³⁷ ClO ₂	OCDD (S)		
357.8516		M+4	C ₁₂ H ₃ ³⁵ Cl ₃ ³⁷ ClO ₂	PeCDD	471.7750	M+4		¹³ C ₁₂ ³⁵ Cl ₆ ³⁷ Cl ₂ O ₂	OCDD (S)		
367.8949		M+2	¹³ C ₁₂ H ₃ ³⁵ Cl ₄ ³⁷ ClO ₂	PeCDD (S)	513.6775	M+4		¹³ C ₁₂ ³⁵ Cl ₇ ³⁷ Cl ₂ O ₂	DCDFPE		
369.8919		M+4	¹³ C ₁₂ H ₃ ³⁵ Cl ₃ ³⁷ Cl ₂ O ₂	PeCDD (S)	[422.9278]	LOCK		C ₁₀ F ₁₇	PFK		
408.7974		M+2	C ₁₂ H ₃ ³⁵ Cl ₆ ³⁷ ClO	HxCDFPE							
[354.9792]		LOCK	C ₉ F ₁₃	PFK							
3		373.8208	M+2	C ₁₂ H ₂ ³⁵ Cl ₄ ³⁷ ClO	HxCDF						
		375.8178	M+4	C ₁₂ H ₂ ³⁵ Cl ₃ ³⁷ Cl ₂ O	HxCDF						
		383.8639	M	¹³ C ₁₂ H ₂ ³⁵ Cl ₄ ³⁷ ClO	HxCDF (S)						
	385.8610	M+2	¹³ C ₁₂ H ₂ ³⁵ Cl ₃ ³⁷ ClO	HxCDF (S)							
	389.8156	M+2	C ₁₂ H ₂ ³⁵ Cl ₄ ³⁷ ClO ₂	HxCDD							
	391.8127	M+4	C ₁₂ H ₂ ³⁵ Cl ₃ ³⁷ ClO ₂	HxCDD							
	401.8559	M+2	¹³ C ₁₂ H ₂ ³⁵ Cl ₄ ³⁷ ClO ₂	HxCDD (S)							
	403.8529	M+4	¹³ C ₁₂ H ₂ ³⁵ Cl ₃ ³⁷ ClO ₂	HxCDD (S)							
	445.7555	M+4	C ₁₂ H ₂ ³⁵ Cl ₆ ³⁷ Cl ₂ O	OCDFPE							
	[430.9728]	LOCK	C ₉ F ₁₇	PFK							

(e) The following nuclidic masses were used:

- H = 1.007825
- C = 12.000000
- ¹³C = 13.003355
- F = 18.9984
- O = 15.994915
- ³⁵Cl = 34.968853
- ³⁷Cl = 36.966903

S = internal/recovery standard

LDC #: 19191A21
SDG #: See cover

VALIDATION FINDINGS WORKSHEET
Sample Calculation Verification

Page: 1 of 1
Reviewer: [Signature]
2nd reviewer: [Signature]

METHOD: HRGC/HRMS Dioxins/Dibenzofurans (EPA SW 846 Method 8290)

(Y) N N/A . Were all reported results recalculated and verified for all level IV samples?
(Y) N N/A . Were all recalculated results for detected target compounds agree within 10.0% of the reported results?

$$\text{Concentration} = \frac{(A_x)(I_s)(DF)}{(A_s)(RRF)(V_s)(\%S)}$$

- A_x = Area of the characteristic ion (EICP) for the compound to be measured
- A_s = Area of the characteristic ion (EICP) for the specific internal standard
- I_s = Amount of internal standard added in nanograms (ng)
- V_s = Volume or weight of sample extract in milliliters (ml) or grams (g).
- RRF = Relative Response Factor (average) from the initial calibration
- Df = Dilution Factor.
- %S = Percent solids, applicable to soil and solid matrices only.

Example:

Sample I.D. 3 . 2 :

$$\text{Conc.} = \frac{(365016)(4000)}{(1342580)(1.72)(1004)(0.913)}$$

= 6.90 $\mu\text{g/g}$

#	Sample ID	Compound	Reported Concentration ()	Calculated Concentration ()	Qualification